Video Smart Pet Feeder

# Quick Operation Guide

Please read the quick instructions carefully when using the product



After opening the package, please make sure that the pet feeder is in good condition Please check the list to see if the accessorie are complete. Feeder machineX1

Power cable X1 Quick operation guider X1

## First use

and take out the cord

The desiccant is put in the dryer box

by default, and it should be replaced

regularly after long-term use (Clean







Three D size batteries can be installed in the battery compartment for manual feeding when there is no power (optional)



## Button Function Description

RESET button: Mode switch/ RESET 1. Long press 10 seconds to make two "ding dong" sound to restore factory settings in both connected and locked states, 2. Long press 10 seconds to make two "ding dong" sound and switch into distribution network mode(Quick configuration/hot configuration)

Microphone button: Long press and sound a beep to start recording, release and make two "beep" sounds to end and play the recording. Recording duration can be up to 10 seconds

Feed Button: Short press and feed the food, long press the red indicator light for 10 seconds to lock the device, then press the red indicator again for 10 seconds and flash twice to unlock, it cannot be set in the


## Light instructions


- Red light:Flashing when lock/unlock/ mode switch
- The blue light (signal indicator) is always on means working normally, Flashing quickly means waiting for network distribution.

download the APP ar complete the installation.



## Product Appearance Introduction






## How to use App TUYA Smart" App Operation steps











🛦 Add feeder successfully 🛮 🚓 Waiting for network

the name of the feeder







♥ Tenda, 299440

- . . .

NAME AND DESCRIPTIONS

Select 2.4 GHz Wi-Fi Network and enter password.

200 B 21 P



Feeder Interface function

Speaker: Turn on and you can hear the feeder sound.

Photograph: Take pictures of your pet and save them

Microphone: Click the icon to turn blue, you can talk with your pet through the phone.

Recording: Record pet videos and save phone photo

albums.

Playback: Playback is not supported on this device.

Alarm: This device does not support the alarm

function
Cloud video playback: This function is a fee-based

Setting options: device name, shared device, device

information basic function settings, motion detection

settings common problem and feedback, firmware


Cleaning And Maintenance

caused by food residues left too long.

for your pet. Feeding: Feed your pet by hand

Regular feeding: Set a daily feeding time and amount

HD/STANDARD definition: Video definition can be selected according to the network speed. 8 Full screen: Click to watch the video in full screen.




+ Schedule

Add sharing and link accounts (become family members only

After the feeder has been used for a certain period of time, the food plate and bucket

should be cleaned with detergent, so as not to affect the health of pets due to the bacteria

From salesmon rives for about +1-20 security.



6- Settings

Detector Alarm Settings

Office Institution
Office Natification

FRQ & FreeBack

Service Update Inc., pinner involuter 5


Remove Device

Click the step 10 at the top to access

(Share with multiple people to operate


Wilder States

Additioning Sees



### Ouestion 4: The pet feeders are often offline.

Answer: Press and hold the manual feeding button t refer to the manual.l



Answer: a. The food bucket runs out of food, resulting in no food falling down. b. The pick in the food bucket has come loose so that the food can't be pulled down. Just put the picks in the container, c. The food bucket is not in alignment resulting the motor below is idling, d. Food particles are too large or the surface is rough and oily, resulting in food caking, if the pick can not go down then you can put less food. f. there are too many food piled up in th

### Question 2: APP prompts that 2.4GWiFi network is only supported, please select again, or the Question 1. The pet feeder is configuration is unsuccessful for many times

Answer: Feeders do not support 5GWIFI, if it is a dual-band router, please go inside the router turn off the 5GWIFI signal. If the mobile phone has a router management APP, you can bly enter the management software to turn off SGWIFI. If there is no management software, please input the IP address of the router in the mobile phone or computer browsei which is generally 192.168.1.1 or 192.168.0.1. Enter the router password to enter, find the wireless settings, turn off 5GWIFI. After saving and restarting the router, reconfigure the feeder. After setting up the feeder, 5G WIFI can be restarted.

Video Smart Pet Feeder Common Troubleshooting

7 seconds to reset the device, power off the router and restart. Wait 2 minutes before configuring it. eeders do not support 5GWiFi and Chinese name. rn off 5G connection and reconfigure 2.4Gwifi. If the configuration is not successful, you can turn or the hot spot with your phone and connect another phone to the hot spot then configure, the details can

Change the channel to 7 or 11 or try another channel. Reduce interference from surrounding wif and improve compatibility.

### Problem 5: There is no food or pet feeder doesn't feed food or the food is stuck.

outlet aisle, which will fall off after pet eating, Reduce the number of meals at feeding time. g. Clean the feeder, feeder food bucket and Food residue inside the device with a dry cloth.

The device has been approved for use in EU countries and is therefore provided with the **CE mark.** All necessary documentation is available on the website: www.electric-collars.com Changes to technical parameters, properties and printing errors reserved.

### Service center and distribution

Reedog, sro Sedmidomky 459/8 101 00 Prague 10

Phone: +1 646 980 4569

Email: info@electric-collars.eu