

SELF-ADHESIVE WALLPAPERS **dovido**

Dear customer, thank you for ordering a self-adhesive wallpaper in our e-shop. We make wallpapers with love and our goal is to bring joy and a fresh breeze in the form of new decorations to your home.

Self-adhesive wallpapers are printed on high-quality material with a fine texture and matte surface. The print is applied with modern UV-led technology on 90 µm thick wallpaper. Thanks to inkjet printing, our wallpapers boast excellent surface durability and color fastness. Self-adhesive wallpapers are PVC-free (do not contain polyvinyl chloride). The printing technique saves the environment, the product is environment-friendly and suitable for every room.



HOW TO INSTALL SELF-ADHESIVE WALLPAPER

Here are instructions for applying the wallpapers, which will be a great help during the actual application.

1. Before you start, make sure the place where you want to stick the self-adhesive wallpaper is firm, smooth, and dry. The better you prepare the base, the better the overall result will be. Feel free to use a primer as well.
 2. Lay out the different parts of the wallpaper in the correct order. Check that the edges fit together correctly and that the pattern is not broken. If you notice any defects, please do not hesitate to contact us.
 3. Using a spirit level and a ruler, mark straight vertical lines every 75 cm on the selected wall to which you will attach the edges of the wallpaper. Feel free to leave an overlap of about 5 cm at the top and bottom. By overlap, we mean the excess material outside the main area to be wallpapered. You can trim this remaining excess later with a knife. If applying wallpaper around a window, start from the window area.
 4. Cut the self-adhesive wallpaper into individual parts. Take the first part of the wallpaper, making sure you have the correct piece in your hand. Be careful to avoid surface contamination. Carefully apply the first part of the wallpaper. It is important to start with the first piece straight so that the entire wallpaper motif fits beautifully on the wall afterward.
 5. Carefully peel off part of the wallpaper. Next, attach the peeled part of the wallpaper to the wall and slowly press the whole piece down from top to bottom. Check that the first piece is aligned against the guide lines.
- *We advise you to avoid constantly peeling and sticking parts of the wallpaper. If the parts are continuously handled, the wallpaper could become less adhesive.*
6. Remove unevenness and air bubbles. Use a circular motion from the center of the wallpaper to its edges.
 7. Trim the overlapping parts of the wallpaper already glued on the wall with a knife using a ruler. Even a small detail will contribute to a perfect result. Repeat the same procedure for the other parts. Do not overlap the individual strips, place them side by side.

We hope these instructions help you achieve a perfect result. If you have any further questions, feel free to reach out. Enjoy your new wallpapers and the transformed look of your space!