

INSTRUCTIONS: HOW TO GLUE WALLPAPERS ?

You will need

1. Wallpaper glue
2. 1 liter of cold water
3. Glue preparation container
4. Pencil and paper (painting) tape
5. Scissors
6. Measuring aids (ruler, meter...)
7. Water-level
8. Glue brush
9. Wallpapering brush
10. Knife
11. A soft sponge or a cloth

Before you start

1. Prepare a wall for wallpapering. The surface should be clean, dry and degreased.
2. Cut a roll of wallpaper along the dotted line.
3. Arrange the individual parts of the wallpaper in the correct order. Check that the edges are correctly aligned and that the pattern is not broken. If you notice any defects, do not hesitate to contact us - we will replace the wrong roll for you.
4. Prepare the glue. If you use wallpaper from our additional offer, mix the contents of one bag (50g) with a liter of cold water and let it stand for 15 minutes. Then mix the glue again and you can start the application.

Note: Due to the drying of the adhesive, we do not recommend applying wallpaper to places with low air humidity or temperatures below 10 ° C. The optimal temperature for the wallpapering and drying process is between 18 - 21 ° C.

Non-woven wallpaper application

1. Using a water level and ruler on the selected wall, mark straight vertical lines every 50 cm to which you attach edges of the wallpaper.
2. If you have chosen a wall with a window for the wallpaper application, we recommend that you start gluing the wallpaper from the window.
3. Apply glue to the wall in place designated for the first part of the wallpaper. Spread a thin, continuous layer slightly beyond the edge of the indicated guide line. Do not apply wallpaper glue.
4. Take the first part of the wallpaper. Make sure you have the correct part turned in the desired direction. Carefully spread out the roll to avoid the soiling of the surface of the wallpaper.
5. Place the top of the wallpaper against the wall covered with glue and slowly press the whole part from top to bottom.
6. Make sure the first part is aligned with the guideline. If not, gently slide it to the correct position.
7. Using a brush, carefully smooth the surface of the wallpaper, removing unevenness and air bubbles. Use circular movements in the direction from the center of the part to the sides. Start at the top.
8. Repeat the same procedure for other parts of the wallpaper. Make sure that the edges of the wallpapers are contiguous.
9. Excess glue can be removed with a dampened soft sponge or cloth. When wiping, be careful not to damage the surface of the wallpaper.
10. After applying and smoothing the wallpaper, cut off any excess parts, including the white edges, with a clean, sharp knife. Using a blunt knife can damage the wallpaper.

After applying the wallpaper

1. Check again for the full adhesion of the wallpaper to the wall as well as for its alignment and the correct continuity of the pattern. The recommended distance for visual inspection is 1-2 meters. Immediately after gluing the wallpaper, it is still possible to move it slightly to the correct position.
2. Use a paint roller to smooth out the last bumps. There may be small air bubbles under the wallpaper that cannot be removed - but these should be completely absorbed in 1-3 days.
3. Remember to ensure air circulation and a temperature higher than 10 ° C in the room.
4. Do not try to speed up the drying process by using any heaters and similar devices. Avoid intense heating in the room.