



运动发声球充电版 使用说明书

产品介绍



包装清单



产品参数

尺寸	9 x 9 x 23厘米
重量	175克
材质	ABS + PP
电压	3.7伏

电池规格

类型	聚合物锂电池
容量	300毫安
充电时长	0.75 - 1小时
满电工作时长	1.5 - 10小时

使用说明

1. 对该产品进行充电，直到指示灯熄灭。
2. 将杆子用力插入产品顶部的圆孔内，提起杆子可以将产品带起来则表明杆子安装成功。
3. 按下“MODE”键，选择合适的工作模式。
 - A. 长按“MODE”键2秒，产品开机并进入运动发光模式。
 - B. 再按“MODE”键，产品切换到运动发光发声模式。
 - C. 开机状态下按“MODE”键可以任意切换工作模式，长按“MODE”键2秒后，产品关机。
4. 产品在任何模式下都只会工作1分钟，需要宠物触碰后才能被激活并继续工作，没有被触碰将会在4小时后关机。（在等待激活期间LED灯会每隔3秒闪亮一次）
5. 当产品运行速度变慢，出现间歇性运动或停止后无法开机时，说明电池电量已经不足，请使用USB充电线给产品充电，充电时LED灯常亮，充满电后LED灯会熄灭。



插入带羽毛的杆子 长按“MODE”键2秒开机（关机）

注意事项


1. 充电前请关闭产品，充电时产品不可以使用。
2. 将产品给宠物使用前请去除标签和包装。
3. 请在平坦干燥的地面上使用产品，远离水、火、高温、脏污的地方。
4. 建议不要在长毛绒的地毯上使用产品，可能会卷入毛绒导致球体卡住不转。
5. 产品不可以水洗，如有发现脏污，请用布擦拭干净。
6. 如果羽毛配件脏污或破损，可以去单独购买来更换。
7. 羽毛配件已通过环保安全测试，并经过高温消毒灭菌，请放心使用。

警告


1. 该产品专为宠物设计，不是儿童玩具，为防止意外发生，请将产品放置于儿童无法接触的地方。
2. 如果发现产品受到损坏或者变形，请不要给宠物使用。
3. 随意丢弃此产品可能会对环境造成影响，请妥善回收处理。

Operation

1. Charge the product until indicator light turns off.
2. Insert the pole firmly into the hole on the top.
The pole is install successful if it is lift product up.
3. Press "MODE" to select preferred play mode.
 - A. Press 2s to power on and enter rolling lights mode.
 - B. Press again to enter rolling lights sounds mode.
 - C. Press switch to change mode randomly in power-on state, press 2s one more time to power it off.
4. It will play 1 minute in any mode and reactive by touch.
It will auto power off without any touch after 4 hours.
(Light will flash every 3s while waiting for activation)
5. The battery is low if product slows down or intermittent rolling, please use USB cable to charge, the light is always on during charging and will go out once fully charged.



Insert the pole with feather



Press "MODE" 2 seconds to power on (power off)


Attention

1. It must be power off and can't use during charging.
2. Remove all packaging before using it with pets.
3. Please place product on a flat and dry ground, away from water, fire, high-heat and dirty place.
4. It isn't recommended to use product on shag carpet.
The fluff will cause the ball to get stuck.
5. It can't be wash, please wipe it with cloth if any dirty.
6. Feather can be buy and replace if dirty or damaged.
7. Feathers have been passed safety tests and sterilized at high temperatures, please feel relieved to use.


Warning

1. The product is designed for pets only, not for kids.
Keep it out of reach of children to prevent accidents.
2. Please remove it from pets if any broken or deform.
3. It will affect environment if discard product casually.
Please dispose of properly.

Rolling Tumbler



In The Box



Product Parameter

Size	9 x 9 x 23cm
Weight	175g
Material	ABS + PP
Voltage	3.7V

Battery Specification

Type	Li-Polymer Battery
Capacity	300mAh
Charge Time	0.75 - 1Hour
Work Time	1.5 - 10Hours

Rolling Tumbler Cat Toy (USB Charging) Operation Manual