


QUICK USER CARD



TRAINING OPERATION



- 1 Power On:** Press the  button to turn on the devices.



- 2 Dog Selection:** Press the dog channel switch button to cycle among 1-2-3 channels.




- 3 BEEP Training:** Press the BEEP button, the receiver emits 2 beeps. Long press the beep button to execute the instruction without interruption.



- 4 Vibration Training:** Press the vibration button, the receiver starts to vibrate. Long press the vibration button to execute the instruction without interruption.



- 5 E-Shock Training:** Press the E-Shock button and the receiver will release the electric shock. Intensity 0 means the E-Shock is off. The E-Shock does not support uninterrupted execution. Long press is invalid. You must press it every time.



QUICK USER CARD




PAIRING OPERATION



Tips: In the 1-pair package, the receiver and controller are already paired on channel 1 by default.

- 1 Operate The Receiver:** In the shutdown state, press and hold the power button for 5 seconds to enter the pairing state, with the red and green lights flashing alternately. At this time, release button and the receiver is waiting for the pairing signal.



- 2 Operate The Remote:** First select the desired remote control dog channel, after the receiver is ready for pairing, press and hold the remote control **V** key for 3 seconds, the remote control will transmit a pairing signal.



- 3 Automatic Pairing:** When the receiver receives the pairing signal, the red and green lights stop flashing alternately, and 3 beeps sound, indicating that the pairing is successful. At the same time, the remote control channel number will also flash for 3 seconds, indicating that the pairing is successful.



- 4 Change The Channel:** If you want to change the receiver's channel, please repeat the above operation.