



6-Meal Automatic Pet Feeder F6



6-Meal
Automatic Feeder
User Guide



Meet Your Automatic Pet Feeder



Pet Feet Protection





Product parameters

Product Name:	6-Meal Automatic Pet Feeder
Item No.:	F6
Dimensions:	W320mm*D320mm*H83mm
Net Weight:	1KG
Power:	Three Alkaline C Batteries(not included) or Type B Micro USB Adapter(5V 1A)
Materials:	ABS
Capacity:	180ml * 6portions(Around 90g/portion)
Time Display:	24-hour display

Assemble & Disassemble



Press down the both side of the top lid and rotate in the direction of the arrow to disassemble the top lid.





1. Test Before Using:

1. Plug in the micro-USB cable or install three “C” size batteries and switch on, then you can start to set up your automatic pet feeder.




2. Please long press “” button for one second to check if the food tray rotates properly.

2. Unlocking The Screen




If no activity takes place in 30 seconds, the unit will shut down and enter standby mode. Press the “” and “” button at the same time for 1 second to unlock the screen and follow the instructions below to manage the settings.

3. Set Current Time:

1. Press “” button, the hour digits will flash.

2. Press “” and “” button to find current hour and press “” again to save.

3. Once hour is saved, the minute digits will flash.

4. Press “” and “” button to find current minute and press “” again to save and enter First Meal Settings.



4. Set First Meal Time:

1. When hour digits and “①” are flashing, repeat step 1 to set the feeding time.

2. Press “⚙️” shortly to save the schedule and go to the second meal settings. (If only 2 or 3 meals needed, please long press “⚙️” button to return to the current time page, your feeding schedules will be automatically saved).



5. Restore Factory Setting:


1. Press “⚙️” button, hours digits will flash.



2. Hold “△” and “⚙️” buttons at the same time to clean all programmed meals and settings.



FAQ

1. Instant Feeding:

Please hold “” for 1s to have an instant feeding. The food tray will rotate one meal.

If food tray doesn't rotate, please press “” and “” buttons at the same time to unlock the control panel.

2. Feet Protection Alarm:

The motor will rotate back when your pets' feet enter the food outlet, [E1:30] will show on the screen and it will return normal after 30 seconds' countdown.

3. Restore Factory Settings:

Please press both “” and “” button for 3 seconds when any of the digits are flashing.


4. Device Abnormal:

[E4:--] will show on the screen, the feeder will stop working, please contact seller to replace the feeder.

5. Low Battery Indicator:

Please replace the battery in time when the low battery indicator flashes.

6. Save and Exit Current Settings:

Long press “” button to return to the current time page, your feeding schedules will be automatically saved).

Important Safety Information

Proper safety warning information can avoid potential danger for people and pets. Please read the safety information carefully.

1. Do not place anything on top of the feeder.
2. The feeder is suitable for operation by users over 12 years old.
3. Suit for both wet and dry food.
4. Support both power supply and Micro USB Interface power supply.
5. The feeder body is forbidden to dip in, or it will cause the feeder broken.
6. When the low voltage indicator is solid, please replace the battery in time. If you do not use the battery for a long time, please take out to avoid battery corrosion.
7. When both plug in and install the battery, power supply is in priority.