


#### 01 / Meet your Smart Feeder LCD Screen Right Button Left Button short/long press to increase the countdown time of the respective tray in 15-minute increments. short/long press to increase the down time of the respective tray in 15-minute increments. short/long press to reduce the ---<sub>6</sub> μress to reduce ι. countdown time of the respective tray in 15-minute increments. short/long press to reduce the countdown time of the espective tray in 15-minute OPEN Short press to open the left tray, then the right one. - Right Tray Long press for more than 5 seconds to reset the feeder to factory setting! Left Tray Battery Compartment 0 0 Anti-skid Pad



02 / Specification

Communication: Bluetooth

Power Input: 1.5V AA LR6 Battery \* 4

Suitable Pets: Cats and Small Size Dogs

Manufacturer: SkyRC Technology Co., Ltd.

Guanlan, Longhua New District, Shenzhen 518110, China

Capacity Per Compartment: 355ml (About 4.23 Oz ) Material: ABS

\*While choosing replacement batteries, please note a maximum cell voltage of 1.5 volts.

Address: 4,5,8/F, Building No.4, Meitai Science Park, Guanguang South Road, Guihua,

Model: PF003





Manual


Size: 300x220x92mm

Net Weight: 780g

(11.81x8.66x3.62 in)

(1) Insert batteries






(2) Add food and Program Feedings Short press the OPEN button to open the left tray, and then again to open the right tray, and add food (both dry and wet food).

03 / Operations



An ice pack can be placed at the bottom of each tray to keep it fresh





Close the left and right lids, press the left "+" or "-" button to set the countdown time for the left meal box. Then, repeat the same step on the right tray. When the planned time is reached, the lid of the tray will pop open automatically.It is recommended to set up the feeding plan with the mobile app to save the hassle!







4 App Setup Download the Petoneer app and add devices.



#### 04 / Quick Setup

Scan the QR code on the right and download the Petoneer App, which is available on App Store and Google Play. Click Sign up and Sign in to get walked through to connect the feeder by pressing the + icon.

05 / Icons Explained

(OPEN)

0



short/long press to increase the countdown time of the respective tray in 15-minute

short/long press to reduce the countdown

time of the respective tray in 15-minute

Short press to open the left tray, then the


the feeder to factory setting!

Long press for more than 5 seconds to reset

0







## 06 / Precautions

- 1. Do NOT place ice packs when serving with dry food.
- 2. Do NOT place anything on top of the feeder. 3. This feeder is for both dry and wet food.
- 4. Never rinse the feeder with water.
- 5. Please do not fill food beyond the edge of the tray to avoid failure. 6. When the app alerts on low power, replace the battery in time. If it is not used
- for a long time, please remove the battery.
- 7. Bulging of the ice pack after freezing is normal. 8. NEVER try to eat the ice pack. When not in use, place it in a dark place to avoid direct
- 9. This feeder is suitable for cats and Small Size Dogs.

### 07 / Certifications

This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular in stallation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two

conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

### FCC Radiation Exposure Statement:

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled enviroment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

**Environmental Conditions** Operating Temperature: 32 °F to 104 °F, (0 °C to 40 °C) (indoor only)

SkyRC Technology Co., Ltd. declares that this Two-Meal Feeder(PF003), is in compliance with the essential requirements and other relevant provisions of the Radio Equipment Directive (2014/53/EU).

### Environment friendly disposal

You can help protect the environment!

Please remember to respect your local regulations: dispose of nonfunctional electrical equipment with an appropriate waste disposal center.

# **(**€ 🗵

Manufacturer: SkyRC Technology Co., Ltd.

4, 5, 8 Floor, Building 4, Meitai Science Park, Guanguang Road, Guanlan, Longhua District, Shenzhen, China.

# Read all the instructions

When using electrical appliances, basic safety precautions should always be followed, including the followina:

1.Do not touch hot surfaces. Use handles.

2.To protect against electric shock do not immerse cord, plug into water or other liquid. 3. Close supervision is necessary when any appliance is used by or near children

4. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or

### taking off parts, and before cleaning the appliance.

5.Do not operate any appliance with a damaged cord or plug, should the appliance malfunction, or if it has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair or adjustment

6. The use of the accessory attachments is not recommended by the appliance manufacturer as it may cause injuries.

7.Do not use outdoors.

8.Do not let the cord hang over edge of table or counter, or touch hot surfaces. 9.Do not place on or near a hot gas or electric burner, or in a heated oven.

10. Always attach plug to appliance first, then plug cord in the wall outlet.

11.Do not use the appliance for other than intended use.

12 WARNING: Never leave the appliance unattended while

13. Warning: keep the supply cord away from heating tip and metal enclosure while using. 14. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instructions concerning use of the appliance by a person responsible for their safety.

15. Children should be supervised to ensure that they do not play with the appliance. 16.If the SUPPLY CORD is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

17.WARNING: This tool must be placed on its stand when not in use. SAVE THESE INSTRUCTIONS.

## **08 /** Warranty Terms

Within the period of warranty, if the product fails with no fault of user operations, it will be repaired at Petoneer's expense. The warranty will not cover product failure in examples below: 1). Intentional damage to the product by the user or third party.

2). Failure to operate or maintain the product following the (QIG) Quick Installation Guide Instructions.


3). Failure by natural wear and tear including but not limited to scratching, corrosion, oxidation

4). Failure by non-authorized repair of the product including but not limited to user's own or third-party repairing attempts or modifications.

All Pictures shown in the manual are for illustration purpose only.

Actual product may vary due to product enhancemen

# 01 / 产品概览



# 配件清单

EN EN

中文 中文



02 / 基本参数

供电方式: 四节5号电池

单格容量: 355ml (约120g)

\*在选择替换电池时,请注意最大电池电压为1.5伏/节。

适用对象: 猫及小型犬

产品型号: PF003

通讯方式: 蓝牙





产品尺寸: 300x220x92mm

**执行标准:** Q/TK 002-2019

产品净重: 780g

产品材质: ABS

保修期:1年

AA LR6电池 x4




取出主机, 打开主机底部电池盖, 装 入四节5号AA LR6电池(注意正负极), 盖上电池盖,液晶屏显示。

物粮食(干粮、湿粮均可)

03 / 使用操作

① 装入电池



② 开盖加粮设置喂食计划 短按 "OPEN" 键打开左餐盒, 再短按 "OPEN"键打开右餐盒,在餐盒里加入宠



餐盒底部可放置冰盒用于保鲜。 \*冰盒需要冰冻后使用!



④ 添加设备,设置喂食计划 下载"Petoneer" APP, 添加设备。

③ 手动喂粮

盖上左右餐盖, 按左边"+"或者"-"按键 设置左餐盒出粮倒计时时间,按右边"+"

或者 "-" 按键设置右餐盒出粮倒计时时

建议手机APP设置喂食计划,更简单。

短按OPEN按键,即可立即出粮。

间。到达预计时间后,餐盒盖会自动弹开。





**(** 


# 04 / 快速添加设备

扫描右侧二维码,按照提示下载安装 "Petoneer" APP, 并注册登录账号, 点击"+"按照提示进行设置。



# 05 / 按键和显示屏图标说明





短按/长按:设置对应餐盒出粮倒计时时间, 减少数值,15分钟为单位。

(OPEN) 短按: 左餐盒开,再短按右餐盒开; 长按:5秒以上恢复出厂设置。



# 06 / 注意事项

- 1. 放干粮时请勿使用冰盒。
- 2. 喂食器顶部禁止放置其他杂物。 3. 本产品干粮湿粮通用。
- 4. 禁止用水冲洗喂食器。
- 5. 请不要将宠粮填充超过食物盆边缘,以免引起设备故障。 6. APP显示低电量时,请及时更换电池。如长期不用,请将电池取出。
- 7. 冰盒冷冻后有鼓包现象,属正常情况。
- 8. 冰盒请勿食用,不使用的状态下,放置阴暗处,避免阳光直射。
- 9. 本机适用于小型犬猫。

中文中文

# 07 / 保修条款

在保修期限内,对于正常使用Petoneer产品过程中,由于非人为导致的损坏,所产生的维修费用 和相关的人工费用,由Petoneer承担。以下情况导致的维修不在保修条款包含中。 (1) 故意行为导致的损坏。

(2)未按照产品使用说明书指引使用、保养该产品。 (3)设备正常磨损、腐蚀、氧化、锈垢、耗损等原因导致的损失。

(4)因在非Petoneer授权维修代理店或用户自身进行维修、改造、清洗而造成的损坏。

\* 为了提供更好的产品,我们会定期进行产品改良。产品实物可能与说明书有差异。

服务热线: 400-808-5869 服务网址: www.petoneer.com

制造商: 天空创新科技(深圳)有限公司 制造地址:深圳市龙华区观澜街道桂花社区观光路美泰工业园4栋4,5,8层

中文 中文

中文中文



The device has been approved for use in EU countries and is therefore provided with the **CE mark.** All necessary documentation is available on the website: www.electric-collars.com Changes to technical parameters, properties and printing errors reserved.

#### Service center and distribution

Reedog, sro Sedmidomky 459/8 101 00 Prague 10

Phone: +1 646 980 4569

Email: info@electric-collars.eu