

USER MANUAL

REEDOG MX – 600 MEDIUM



Function:

- 1) Charging – transmitter and receiver (possibility of charging both parts at the same time)
- 2) Submersible - transmitter and receiver (up to 2 m)
- 3) Adjustable vibration level and el. discharges (range 1–10)
- 4) Choice of 3 modes – sound, vibration and electric.
discharge 5) Possibility of expansion for up to 3 dogs (after purchasing additional receivers)
- 6) Option to turn off the radio and receiver to save battery

Tips:

- 1) Before using the device for the first time, fully charge it and test the functionality of the collar 2) Training always starts at the lowest power level. shocks and always monitor your dog's behavior 3) Before using el. during a fight, first try to alert the dog using sound or vibration 4) Always require only one command to be executed so that the dog is not confused. Be consistent in training and patient at the same time
- 5) Examine the skin on the dog's neck for irritation



Before first use:

- 1) Fully charge the radio using the attached cable (2-3 hours) when discharged, the red light flashes
- 2) Fully charge the receiver using the included cable (2-3 hours) red light flashes when discharged
- 3) Long press the on/off button on the receiver. If it flashes green quickly = it is in pairing mode mode, flashes every 5 seconds after pairing. Turning the receiver off and on is accompanied sound signal.

- 4) Long press the on/off button on the radio and set with the dog selection button (doghead) select dogA**XX**. If you only have one receiver always make sure it is set **AXX**.
(XX stands for set intensity level 01-10)
- 5) If you have multiple receivers, set dog **B XX** or **C XX**.
- 6) Pairing is done using **the sound button** and **the "+" button**, which must be pressed at the same time - in close proximity to the receiver (switched on). When pairing, you will see an automatic increase in level 01,02,03...98,99. After successful pairing of the radio with the receiver, you will hear a sound notification and the indicator light on the receiver will be flash every 5 seconds.

- 7) If you need to split the device for any reason, do so immediately, but using **volume buttons and "-" buttons. The receiver will stay** in pairing mode = it will flash green rapidly.

- 8) Make sure all functions are working properly. To test the el. discharges, attach the attached test diode to the electrodes. discharges, the diode will light up
- 9) Choose the appropriate length of electrodes according to your dog's coat (use longer for long-haired breeds) and using tighten the enclosed plates firmly
- 10) Thread the collar through the receiver (if you want, thread the lanyard through the radio)
- 11) Now the training collar is ready for use

Safety:

To ensure the maximum effect and safety of your dog, check the location of the collar, its sufficient tightening and the correct placement of the electrodes. Also check the skin where the electrodes touch for rash or irritation. In this case, wear the collar for shorter periods of time, or consult your veterinarian

The collar should not be worn continuously for more than 12 hours (this is a general recommendation for all collars, even non-electric ones).

Device malfunction:

The collar does not seem to be working properly:

- make sure both the transmitter and receiver are fully charged
- pair the receiver with the radio according to the instructions
- make sure that the correction intensity is not at zero value
- make sure the correct channel (A, B or C) is selected on the radio
- pair the collar, set the intensity and try the device again

The receiver or transmitter does not charge:

- make sure you have properly connected the connectors to the network and the device
- test both devices for a charger or network fault

My dog does not respond to corrections:

- test the receiver according to the instructions above
- make sure the electrodes are touching the skin
- increase the intensity of corrections

The device has been approved for use in EU countries and is therefore provided with the **CE mark**. All necessary documentation is available on the website: www.electric-collars.com
Changes to technical parameters, properties and printing errors reserved.

Service center and distribution

Reedog, sro

Sedmidomky 459/8 101

00 Prague 10

Phone: +1 646 980 4569

Email: info@electric-collars.eu