

User Operating Guide

Please read this guide thoroughly before operating the Training Dog Device

Important safety information

WARNING (Not for aggressive dogs)

Do not use this product if your dog is aggressive, or if your dog is prone to aggressive behavior.

Aggressive dogs can cause severe injury and even death to their owner and others.

If you are unsure whether this product is appropriate for your dog, please consult your veterinarian or certified trainer.

CAUTION

Avoid leaving the collar on the dog for more than 10 hours per day, it may cause SKIN IRRITATION.

If possible, REPOSITION the collar on the pet's neck every 1 to 2 hours, it will prevent the skin from damage.

When using the shock mode, start from the LOW LEVEL OF SHOCK and look at your dog's reaction. If your pet becomes uncomfortable, STOP USING the collar immediately.

The collar is waterproof, the remote transmitter is NOT waterproof. Make sure the collar is NOT TOO TIGHT, two fingers must fit between the collar belt and your dog's neck.

EXAMINE the neck area of your dog DAILY to ensure the absence of rash and redness.

Do not plug or unplug USB port hard while charging.

These cautions will ensure safety and comfort of your pet. Millions of dogs are comfortable while they wear stainless steel contacts. Some dogs are sensitive to contact pressure. You may find after some time that your dog is very tolerant of the collar. If so, you may relax some of these precautions. It is important to continue daily checks of the contact area. If redness or sores are found, discontinue use until the skin has fully healed.

Page 3

Note:

If the transmitter and receiver collar don't work for a long time, you should charge it fully before keeping it idle, and charging it every one month.

Table of Contents

Overview.....	4
1. Pairing Collar Receiver to Transmitter.....	5
2. Test the Training Device Functions.....	6
3. Collar Fitting.....	8
4. The LED Indicator.....	8
Frequently Asked Questions.....	9
Troubleshooting Guide.....	10
Training Tips.....	11

Common size of different dogs.....12

Main Features

Page 4

Overview

Remote Transmitter

Built-in Antenna

Vibration Button

Beep Button

Channel Button

....

LED Indicator

Shock Button

UP Button

Down Button

Collar Receiver

Charging Port

Power Button

LED Indicator

Contact Point

Page 5

1. Pairing Collar Receiver to Transmitter

Hold the power button of Collar Receiver for 3 seconds into Pairing status, you will hear 1st beep from the collar receiver and the led light will flashing 10 seconds

Click to turn on the collar receiver; Double-click to turn off the collar receiver

Press button on the transmitter to finish Pairing

Hold 3 seconds

Press Beep Button

You will hear 2nd 'beep" from collar receiver, that means pairing is successfully.

If needs to pair the second collar receiver, follow the same steps but needs press channel button change to different channel.

Page 6

2. Test the Training Device Functions

Shock Simulation

Found the test light and put it over the Contact Points of the Collar Receiver.

Press UP button to setting the intensity of 5.

Press the shock button on your Remote Transmitter.

The test light should flash orange indicating the electronic pulse Simulation is operating correctly.

Testing Light

Setting the Intensity of 5

Press Button

Page 7

Vibration Simulation

Setting the intensity of 5.

Press the Vibration button

on your Remote Transmitter.

If done correctly, the Collar Receiver will vibrate.

Vibration Simulation

Beep Simulation

Press the beep button on your Remote Transmitter If done correctly, the Collar Receiver will vibrate.

We suggest you can give the dog Vibration Simulation before following it with Static Shock Simulation.

After training for a while using this method, dog will be aware that after vibration comes static shock.

Vibration will act as a warning, and static shock only acts as a menace that might be necessary sometimes.

Page 8

3. Collar Fitting

The collar receiver should be fitted so that the contact points press firmly against the dog's skin. When properly fitted, you should be able to fit a finger or two snugly in between the contact points and your dog's skin.

When properly fitted, the collar receiver should not move on the dog. The best location for the collar receiver box is either side the dog's windpipe.

A loose fit can allow the collar receiver to move around on the dog's neck. When this happens, the contact points may rub the skin and cause irritation.

If the collar receiver is too tight, the dogs may have difficulty breathing.

4. The LED Indicator

Remote Transmitter:

The LED indicator shows up when any Simulation buttons are pressed or the transmitter is recharging.

It will turned off when the battery charged fully.

If the collar is too long for your dog, trim the collar as follow pictures:

It will blink when it standby within 1 minute.

Page 9

Battery Icon:

It's in the bottom right corner of LCD Screen, when the battery

icon has only 1 bar that means you need to recharge the transmitter. When is charging, the battery icon will change from 1-5

bars. It will stop at 5 bars when it's fully charged.

Collar Receiver Indicator:

It shows up when any of the Simulations are pressed on the transmitter or the battery charged fully.

It will blink when it standby within 5 minutes or the collar receiver is recharging.

It will flash quickly when it's into 10 seconds pairing status.

It will blink once when the battery power low. That means you need to recharge for collar receiver. (Standby is 3 second blink once)

Frequently Asked Questions

1. How old does the dog have to be before using the device?

Your dog should have learned basic obedience commands such as

°Sit° or Stay°. The Collar Receiver might be too large for pets under

15 pounds.

2. Once my dog completes training and is been obeying my commands, will he have to wear the Receiver Collar?

Probably not, but you may try to reinforce training with the Collar.

3. Can I attach a leash to the Collar Receiver?

NO. This can result in pulling the Contact Points too tightly against your dog's neck.

Attach a leash to a separate, nonmetallic collar

or harness. Ensure the extra collar does not put pressure on the Contact Points.

4. How long can I leave Collar Receiver on my dog?

The design of the collar discourages constant wearing.

We recommend not having the dog wear the Collar for more than 12 hour out of every 24hour period.

5. How long should I process my training session for my pet?

Training sessions should be kept positive and short, it is better for about 10-15 minutes long each time.

Page 10

Troubleshooting Guide

1. My dog is not reacting to the collar.

Make sure the receiver/collar is turned on, and check the intensity levels of vibration and static shock. Please make sure it is not set to 0.

Be sure the strap is on the dog tight enough so that both contact points are touching the dog's skin.

The contact points may be too short for your dog's thick or long coat. If you are already using longer contact points, you may need to trim the hair on the dog's neck, so that both contact points are touching the dog's skin.

The intensity level may be too low for dog. Increase the Simulation until the dog responds, usually by a neck movement, head shaking, or looking over the shoulders. The response may be very subtle. If tested for all of the above and the dog is still not responding, please try re-pairing the Remote Transmitter and Collar Receiver.

2. I want to test Collar Receiver myself, but it does not work. When testing the collar by your hands, please touch the two electrodes simultaneously, as touching one electrode will not work.

3. LED indicator light comes on, but I do not feel any Simulation. Your tolerance may be higher than your dog's. You may need to try the unit on your fingertips where sensitivity is higher and/or increase the Simulation level. Be sure both contact points are touching both of your fingertips.

The battery may be low, check the LED indicator light on the transmitter and receiver/collar for battery life.

4. Transmitter has no range, or the Simulation is weaker when my dog is farther away.

Check to see if your fingers are touching the antenna, as the range may decrease substantially.

The range indicated on the unit's box is for flat terrain (line of sight). Heavy brush, trees, hills, buildings, and/or moisture will affect the range of your unit. For the best range, hold the transmitter vertically above your head, and/or try moving to higher ground.

Training Tips

1. Make training sessions short and positive (between 10-15 minutes long for each session) This will enable the dog to keep its attention focused on the trainer.
2. Train one dog at a time.
3. During the first initial training sessions, keep the dog in a familiar outdoor environment. Training in new locations may cause the dog to become distracted, causing you to reinforce commands with the Collar Receiver more than necessary.
4. Use a long leash fastened to a non-metallic collar to help the dog's learning. Ensure the additional collar and leash does not interfere with the Contact Points on the Collar Receiver.

Do not use the remote training collar without a long leash until your dogs is fully trained.

5. More success will occur by teaching the dog a command first before trying to reinforce the command with Remote Transmitter.
6. For basic obedience training, vibration is more useful.
7. Issue one obedience command at a time, this will reduce confusion and allow the dog to remain focused.

Do not use the training device for commands that the dog has not learned.

8. During training, look for all the positive changes in the dog's behavior and remember to reinforce them promptly with ample praise and reward.
9. Avoid over-correcting your dog. Use as little remote correction as possible during the training process.
10. When the dog has become apparently perplexed, shift the focus of the training by drawing the dog's attention to a command they have familiarity.

Example: Tell the dog to sit and give abundant praise and encouragement on successful completion of the sit command.

Page 12

11. Do not use the training dog device to correct or eliminate forms of aggression or biting behavior. When the dog is showing signs of aggressive behavior, immediately contact a professional dog trainer in your local area.

12. Please keep in mind, that you should keep training sessions short and end every session on a high note. Stop training and play with the dog as soon the dog has accomplished a new level of proficiency.

Common size of different dogs

Size	Neck (cm)	Chest Measurement (cm)	Back Length (cm)	Type
Mini	20-22	25-30	19	Chihuahua, Yorkshire Terrier
Small	20-24	29-36	23	Chihuahua, Yorkshire Terrier

				Poodle,Pomeranian
Medium	23-28	35-42	28	Maltese Dog,Shih Tzu
Medium	27-31	41-47	31	Miniature Schnauzer,Pekingese
Large	30-34	46-53	35	Schnauzer English Cocker Spaniel
Large	33-37	52-59	40	Beagle
Huge	43-48	76-84	60	Husky
X-large	47-52	88-97	65	Labrador Retriever
XX-large	52-62	92-100	70	Golden Retriever Old English Sheepdog

Frequency: 915MHz

Transmitter: 3.7V 300ma LiP

Receiver: 3.7V 300ma LiP

The device has been approved for use in EU countries and is therefore provided with the **CE mark**. All necessary documentation is available on the website: www.electric-collars.com
Changes to technical parameters, properties and printing errors reserved.

Service center and distribution

Reedog, sro

Sedmidomky 459/8 101

00 Prague 10

Phone: +1 646 980 4569

Email: info@electric-collars.eu