Thank you for choosing Uahpet!

Uahpet insists on helping pets to live in a way more in line with their nature through scientific and advanced parenting concepts, such as physiology, environment, behavior and psychology.

Scan QR code to get operating instruction manual

support@uahpet.com

Safety Precautions

Failure to comply with the following terms may result in the product not functioning properly or other unexpected losses.

- Please strictly follow the instructions to install and use this product.
- When charging the product or using it while it's charging, please prevent your pets from biting the charging cable to avoid electric leakage.
- Except for maintenance personnel, other people should not repair this product to avoid accidents.
- If children operate the product, please ensure that they are under adult supervision.
- Do not use a charger that exceeds the rated voltage.
- It is recommended to fully charge the product before the first use.
- If you encounter any problems with the product, please contact customer service.

After-sales Service

Accessories Purchase

We recommend that replacing the filter and filter sponge once a month, use with genuine please. www.uahpet.com

Warranty Regulations

From the purchase date on your purchase certificate, the product has a one-year warranty for non-human-caused performance failures, excluding consumables.

Non-warranty regulations

The following conditions (but not limited to) are not covered by the warranty:

- No warranty certificate, missing valid invoice, or exceeding the warranty service period.
- Damage caused by improper use, maintenance, or storage according to the user manual.
- Damage caused by natural disasters such as fire, lightning, or flood.
- The product model or number on the warranty card does not match the actual product.
- Damage caused by non-authorized personnel repair.
- Normal fading, wear, and tear during product use, which are not covered by the warranty.
- Product dysfunction is caused by use in non-compliant areas.
- Random gifts.

uahpet

ZERO

Wireless Pet Fountain
Stainless Steel
Product manuals

Product Introduction

Parts Description

- Water Inlet
- Water Outlet
- Stainless Steel Water Tray
- Gravity Suction Ball
- Filter
- Falling Outlet
- Type-C Charging Port
- Button
- Main unit
- Mode Indicator Light
- Sensor
- Stainless Steel Water Tank
- Suction Cup

Product Specifications

Product Model	UYSJ03	Input Voltage	5V ⎓ 2A
Product material	ABS+304 grade stainless steel	Rated power	5W
Product Capacity	67oz/2L	Battery	5000mAh
Product weight	710g	Wasserdichte Bewertung	IPX6
Product size	273.4×214.4×213.4mm		

Product List

Stainless steel drinking tray	Stainless steel water tank
Main unit Filter	Gravity ball filter sponge
Type-C charging cable	User manual

Product Installation

Confirm that all accessories are included according to the packing list.

Product Installation Steps

STEP 1

Install the filter aligning with the buckle to insert it into place.

STEP 2

Place the stainless steel drinking tray on the water tank.

STEP 3

Insert the main unit and make sure the suction cup is tightly fixed.

Product usage instructions

Filter Introduction

- Soak the filter for 15 minutes before first use.
- Filter must be used in conjunction with the main unit.
- For the health of your pet, it is recommended to replace the filter and gravity ball sponge once a month.

Charging Instructions

- Connect the Type-C charging cable (adapter is not included).
- Charging Time: 5h
- The product can work normally while charging.

Function and light description

Press and hold for 3 seconds to turn ON/OFF

When power on, press the button briefly to switch between the Sensing Mode and Timer Mode. The corresponding mode indicator light will light up, accompanied by a short "beep" sound.

Timer Mode/Sensing Mode

- Timer Mode
  Water is dispensed every 15 minutes
- Sensing Mode
  Water is dispensed when pets approach the fountain.

Lighting description

- bule light flashing alternately: Charging
- Blue light is always on：Charging completed

Maintenance and Cleaning Instructions

- Please clean the water tank, drinking tray, filter, and gravity ball components regularly.
- Please turn off the machine before cleaning.
- Do not soak or clean the main unit for a long time in water. After cleaning, please wipe it dry.
- The water fountain components cannot be cleaned with high-temperature water (please use water temperature below 50 degrees Celsius).

The device has been approved for use in EU countries and is therefore provided with the **CE mark.** All necessary documentation is available on the website: www.electric-collars.com Changes to technical parameters, properties and printing errors reserved.

Service center and distribution

Reedog, sro

Sedmidomky 459/8 101
00 Prague 10

Phone: +1 646 980 4569

Email: info@electric-collars.eu