

Operation

- 1. Charge the product until indicator light turns off.
- 2. Insert the pole firmly into the hole on the top.
The pole is install successful if it is lift product up.
- 3. Press "MODE" to select preferred play mode.
 - A. Press 2s to power on and enter rolling lights mode.
 - B. Press again to enter rolling lights sounds mode.
 - C. Press switch to change mode randomly in power-on state, press 2s one more time to power it off.
- 4. It will play 1 minute in any mode and reactive by touch.
It will auto power off without any touch after 4 hours.
(Light will flash every 3s while waiting for activation)
- 5. The battery is low if product slows down or intermittent rolling, please use USB cable to charge, the light is always on during charging and will go out once fully charged.



Insert the pole with feather Press "MODE" 2 seconds to power on (power off)


Attention

- 1. It must be power off and can't use during charging.
- 2. Remove all packaging before using it with pets.
- 3. Please place product on a flat and dry ground, away from water, fire, high-heat and dirty place.
- 4. It isn't recommended to use product on shag carpet.
The fluff will cause the ball to get stuck.
- 5. It can't be wash, please wipe it with cloth if any dirty.
- 6. Feather can be buy and replace if dirty or damaged.
- 7. Feathers have been passed safety tests and sterilized at high temperatures, please feel relieved to use.


Warning

- 1. The product is designed for pets only, not for kids.
Keep it out of reach of children to prevent accidents.
- 2. Please remove it from pets if any broken or deform.
- 3. It will affect environment if discard product casually.
Please dispose of properly.

Rolling Tumbler



In The Box



Product Parameter

Size	9 x 9 x 23cm
Weight	175g
Material	ABS + PP
Voltage	3.7V

Battery Specification

Type	Li-Polymer Battery
Capacity	300mAh
Charge Time	0.75 - 1Hour
Work Time	1.5 - 10Hours

Rolling Tumbler Cat Toy
(USB Charging)
Operation Manual