


# 正面



**Pet Fountain**

**Before we start: Care instructions**


To keep providing fresh, clean water for your pet, remember these three simple tasks:

**Refill often.** Keep the water level up. The pump is designed to work in at least one inch of water. The pump can fail if it runs dry.

**Clean your pump and your fountain.** Take your pump and fountain apart to clean with soap and water every two to four weeks. Be careful not to get soap in the filters, as it will not rinse out. The plastic filter housing, stainless bowl, and stainless tower are dishwasher safe.


**Replace your filters.** Replace the carbon filter every four weeks when you clean your fountain. Replace the foam filter every two months.

**What you have:**



**Setup instructions**

**1 Install the foam filter and the pump:**




Insert the pump into the foam filter and set both down into the round inside the bowl. Press down so the suction cups attach.

Feed the usb cord down into the bracket hole and out through the notches on the bracket bottom.

Insert the cord cap. This holds the cord in place.

# 背面


**2 Install outlet pipe and filter tray.**



Align the outlet pipe with the water pump outlet, and press them tightly.

Align the notch and install the filter tray

**3 Install the filter, lid and flower accessory.**




Take out the filter unit, soak it in clean water. Rinse it slightly with water

Install the filter in the filter tray

Install lid, flower in sequence, connect the power adaptor

**Use instructions**




Place the fountain where your pet will use it. Fill the bowl with water, leaving a half inch of space between the water and the rim. Make sure your hands, the cord and the power adaptor are dry, then plug the fountain into an outlet.

**Keep health and happiness flowing!**

**To extend product life, please clean the pump every 2 weeks.**

1. Remove the Pump Cover
2. Clean the pre-filter grate with soap and warm water.
3. Remove the Impeller and clean the parts with soap and warm water.



Pump Body

Impeller

Pump cover (With pre-filter grate)

**Cautions**

1. Be sure to shut down and disconnect the power supply for safety when the equipment is not in use.
2. This product is for indoor use only.
3. The power adapter and wire plug must not be flooded during cleaning.
4. This product is not allowed to run without water (can be ignored for models with the function of outage automatically without water).
5. Please disconnect the power supply before maintaining and cleaning the machine.