


Cutter Cleaning



Use brush to clean the cutter.



Disassemble the blade and use brush to clean.

Note



1. Never willfully disassemble the product.
2. Water must not be used to wash the clipper, keep away from the dampness while operating.



3. Only use a little wet cloth or neutral liquid soap to clean the product.
4. Never charge the product above 40°C heat source or below 0°C environment.

*Slight heating during the operating or charging is normal case

*After the battery life expires, take off and throw the battery in safe manner into the designated recycling site. Never dump it randomly.

DANGER

To reduce the risk of injury or death by electric shock:

1. Do not reach for an appliance that has fallen into water. Unplug immediately from the outlet.
2. Do not use while bathing or in a shower.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink. Do not place in or drop into water or other liquid.
4. Except when charging, always unplug this appliance from the electrical outlet immediately after using.

CHARGING THE BATTERY

Before the equipment is used for the first time, it should be charged 3-5 hours. Plug power cord directly into unit. Be sure clipper is switched OFF when charging. During charging, the charge indicator is illuminated.

LITHIUM-ION BATTERY DISPOSAL AND RECYCLING:

Do not attempt to remove the battery. Lithium-ion batteries can explode, catch fire, and/or cause burns if disassembled, damaged, or exposed to water or high temperatures.



Professional clipper

DESIGNED FOR THE PROFESSIONAL
Operating Manual



Sharp Blade




Taper Lever



High-performance Battery

Components



Parameters

Clipper For the Professional	Electric Motor	Working Voltage: 3.7V
	Axis Material:	Wearable Brass
Battery	High-performance Environmental-friendly Battery	
	Charging Time:	3-5 Hours
	Operable Time in Full-power:	2-3 Hours
Specific Adapter	Input: 100V-240V 50/60Hz	
	Output: AC 5V 2000mA	

Use the Rechargeable Mode



1. Please switch off the hair clipper before charging and connect to the power supply.
2. When charging, the indicator turns on.
3. If the battery is completely used up, the indicator light will not light up immediately, and the charging indicator light will light up after a few minutes.

The picture is only for reference, please make the object as the standard.

Fixed-length Function

A: Use of Limit Comb: Cropped Hair and Hair Trim Feature: (3, 6, 10, 13mm) Four Lengths Adjustment, Control the Hair Length
B: Cutter Limit Adjustor: Five Lengths Adjustment Within 0.5mm-3mm

1. To determine the length of haircut

2. To select the appropriate limit comb



3. Blade length adjustment



Up and down rotate the adjusting ring to adjust the cutter (0.5mm-3mm)

Mount the limit comb:



Guard assemble
Instruction



Guard Disassemble
Instruction

*The clipper also can be used when it is charging.

The device has been approved for use in EU countries and is therefore provided with the **CE mark**. All necessary documentation is available on the website: www.electric-collars.com
Changes to technical parameters, properties and printing errors reserved.

Service center and distribution

Reedog, sro
Sedmidomky 459/8 101
00 Prague 10
Phone: +1 646 980 4569
Email: info@electric-collars.eu