

Anti-bark collar

Patpet B110 S



User manual

Thank you for choosing our anti-bark collar. Our anti-bark collar is backed by a 100% quality guarantee! If you are not satisfied for any reason, please contact our customer service immediately and we will help you within 24 hours.

Important safety information

Not suitable for aggressive dogs

Do not attempt to use this product to correct the behavior of dogs that are aggressive towards people or other animals. Aggressive dogs may associate the stimulation of the training collar with other control stimuli and become more aggressive. Aggressive behaviour should be corrected by a dog training specialist.

If you are unsure if this product applies to your dog, you may wish to consult a veterinarian or certified trainer. Anti-bark collars should only be used on healthy dogs. If your dog has health problems, take him to a veterinarian first.

Main functions

It is an improved anti-bark dog collar with a digital display and four buttons - **power, vibration, shock and sensitivity button**.

Power button - stage 0-7, stage 7 means fully charged

Vibration button -- Level 0-7, level 7 means the highest vibration and then gradually decreases to level 0 which turns off the vibration mode

Shock button--grade 0-7, the range of shock levels is the same as the vibration, with grade 7 being the highest and grade 0 being off

Sensitivity Button --- Adjustable levels 1-7 are suitable for large to mini breeds. Press the "S" button for 3 seconds and the collar will flash continuously


Press the "S" button again for 3 seconds to switch off. It is suitable for walking your dog at night.

Note: The digital display does not usually indicate when the collar is activated and shows the power level, not the mode level. The anti-bark collar is suitable for all dogs from 6 to 70 kg.

Product weight: 70 g

Collar circumference range for dogs: 12 - 60 cm.

1 2 3 4 5 6 7



Contents of the package

1 X receiver (including nylon collar x 1)
1 X USB charging cable
1 X test bulb
1 x user manual
2x conductive silicone caps

ON-OFF

One press of the power button turns it on. Pressing the power button again for 3 seconds will turn it off.

Use

- * Once you receive the collar, test it first (testing is shown below).
- * After testing, please set the appropriate mode for your dogs and follow the instructions that apply to your current situation! (picture with instructions below)
- * We recommend that you do not use the shock model at first and choose the beep and vibrate mode so that your dog gets used to it. If these are not valid, you can use the shock mode, but please set it to level 1 at the beginning and then gradually increase according to your needs.

A friendly reminder

- * Keep a distance of one finger between your neck and the collar to avoid triggering by shaking/moving/running etc.
- * Do not wear for more than 12 hours a day. If possible, reposition the collar every 1 to 2 hours.
- * Remove the anti-bark collar before bathing.
- * Do not attach anything else to the collar (e.g. a dog lead).
- * Clean the contact point between the collar and the neck every week with a damp cloth.
- * Check the contact area between the collar and neck daily to prevent rashes or sores.

The principle of operation of the product

This product uses vibration sensors to differentiate sensitivity. When the dog barks, the sensors are triggered and so is the product. The collar emits an audible signal, then a vibration and finally a shock. (depending on the setting).

Automatic protection mode

If the collar is activated 7 times within one minute, it will enter the automatic protection mode and "E" will flash on the display. One minute later, the product switches back to the working mode.

In the automatic protection mode, the product returns to the working mode by pressing any button.

Recharge

Gently press the power button to see how much power is left. After 1 hour of charging, you will get 14-20 days of use.


When the product is charging, the digital display shows the energy status and continues to flash. When the product is fully charged, the digital display shows "7".

Rechargeable battery (280 mAh)

Adapter not included
Adapter current is less than 1 A

Testing

- Switch on the device
- Set the sensitivity to level 5-7 and the impact higher than 0.
- Wear the tester on the conductive silicone tabs behind the collar.
- Speak into the collar and say "woof" (as short as possible) to trigger the sensors. Since the frequency of the human voice is different from the frequency of the dog's voice, try again.
 - The collar beeps, then there is a vibration and finally a shock. The device is now ready for use.



Frequently Asked Questions

Question: On which part of the dog's body is the receiver placed?

Answer.

Question: Why doesn't it work immediately upon arrival?

A: First make sure the product is charged, set the sensitivity of the product to level 7.

Question: Why does the product not work when the dog barks?

A: Make sure the product is close to the dog's neck, and if necessary, increase the sensitivity .

Question: Can I not use shock mode?


A: Of course. Please set the shock mode level to 0 first.

If you have any questions about our anti-bark collar, please contact our customer service immediately.

Attention:

Question: On which part of the dog's body can the receiver be placed?

Answer.



**Keep a distance of one finger between the neck and the collar.
to avoid triggering when shaking/moving/running etc.**



Please remove the normal collar before putting on the anti-bark collar.

Tips

You should choose these features according to the size of your dogs. For detailed instructions on which size to choose, please refer to the dog size reference chart.

The degree of sensitivity most suitable for your dog.

You can put the collar on the dogs without turning on the device so that they can adapt to the collar.

Tips on how to choose the optimal sensitivity for your dogs:

Size of the dog	Small	Medium	Large	Giant
Senstivity setting	5-7	4-6	2-5	2-5

You can adjust the sensitivity from the highest sensitivity level 7. If your dog is used to the sensitivity levels, you can lower the sensitivity level.

We recommend using the sound function first (Sound is the default setting), then choose the vibration or static shock function depending on how your dog reacts to the collar.

We recommend using the static shock function from the weakest level 1.

The device has been approved for use in EU countries and is therefore provided with the **CE mark**. All necessary documentation is available on the website: www.electric-collars.com
Changes to technical parameters, properties and printing errors reserved.

Service center and distribution

Reedog, sro
Sedmidomky 459/8 101
00 Prague 10
Phone: +1 646 980 4569
Email: info@electric-collars.eu