




V.76

[www.petoneer.com](http://www.petoneer.com)




NutriCare Feeder  
User Manual

Model: PF009

Please read this manual carefully before using.  
Keep the manual in a safe place for future reference.

## 01 / Inside the box



Feeder\*1



Bowl\*1



Ice Pack\*1




RFID Tag\*2



Collar\*1




Manual\*1




USB Type-C to  
USB-A 2.0 Cable (1.2M)\*1

## 02 / Meet NutriCare




## 03 / Operations

- ① Ensure there are no obstacles within 50 cm in front, left, and right of the device, and avoid placing it on metal surfaces to ensure proper sensor functionality.




- ② **Power Supply:**

- Battery-powered (recommended): Open the battery compartment on both sides of the bottom of the device, insert 4 LR14 alkaline batteries (pay attention to the positive and negative poles), and close the battery compartment.
- It is recommended to use high-quality alkaline batteries (battery life is approximately 120 days). When the indicator light flashes red, it means the battery is low. Please replace the batteries in time.
- This product does not include battery. Please prepare your own.
- If the batteries are not used for a long time, please remove them.





- USB-powered: Insert the USB power cord into the port on the back of the device, connect to an adapter, and power on.
- This product does not include a power adapter. Please prepare your own.
- When both battery power and USB power are connected, the device will prioritize USB power.



USB-powered


### ③ Adding Food:

- Short press the button to open the lid.
- Remove the food bowl and add food to the bowl. If you need to keep the food fresh, you can place a pre-frozen ice pack at the bottom of the food bowl.
- Place the food bowl back into the feeder and close the lid.
- The ice pack needs to be pre-frozen before use.



### ④ Adding Device:

- Download the "Petoneer" app and add the device.



## 04 / Quick Setup

Scan the QR code on the right and download the Petoneer App, which is available on App Store and Google Play. Click Sign up and Sign in to get walked through to connect the feeder by pressing the + icon.



## 05 / Operating Modes

**1. Authorized Mode:** The lid will only open when a pet with an authorized tag approaches for feeding. The lid will automatically close after the pet leaves (the closing delay can be set in the app).

### Adding a Tag via App:

- ① Open the app and go to the authorization mode settings.
- ② Follow the prompts to enter pet information and bind the tag.

### Adding a Tag Manually:

- ① Long press the device button for 3 seconds. When you hear a "beep" and see the indicator light blinking, the device is in add/remove tag mode.
- ② Hold the tag close to the top of the food bowl until the indicator light blinks blue 3 times and you hear a beep, indicating successful authorization.

\*A feeder can bind up to 10 tags in authorized mode. For an enhanced user experience, we recommend using our tags.

### Deleting a Tag:

- ① Open the app and enter authorization management to delete the tag.
- ② When the device is in the add/remove tag mode, place the tag above the lid. If the tag has already been added, the red light will flash, indicating that the tag has been successfully removed.

**2. Sensor Mode:** The lid will open whenever any pet approaches for feeding and will automatically close after the pet leaves (the closing delay can be set in the app).

**3. Manual Mode:** The lid can be opened or closed manually by pressing the button. RFID and sensor functions are disabled in this mode. The device can only be opened manually and cannot be opened automatically.

## 06 / Indicator and Button

Indicator	Status
Blinking Blue	Not connected (Sensor activated)
Steady Blue	Connected (Sensor activated)
Blue and Red blinking alternately	Entering add/remove tag mode
Blinking Blue 3 times	Authorized tag detected / Tag added successfully
Blinking Red 3 times	Unauthorized tag detected / Tag deleted successfully
Steady Red	Device self-check failure or lid abnormal
Blinking Red	Low battery

Button	Status
Short press	Open/close lid
Long press for 3 seconds	Add/delete tag
Long press for 5 seconds	Reset device

## 07 / Specifications

---

**Description:** Petoneer NutriCare Feeder

**Model:** PF009

**Power Input:** LR14\*4pcs or DC 5V  1A

**Dimension:** 240x220x205mm

**Net Weight:** Around 1108g

**Capacity:** 400mL(1.69 cups)

## 08 / Precautions

---

1. Do not use the ice pack when feeding dry food.
2. Keep the top of the feeder clear of any objects.
3. Do not rinse the feeder under running water.
4. Avoid overfilling the feeder with food.
5. Replace the batteries when the low battery indicator appears. Remove batteries if the device will not be used for an extended period.
6. It is normal for the ice pack to bulge after freezing.
7. Do not consume the ice pack. Store the ice pack in a cool, dark place when not in use.
8. Place the feeder in a cool, dry, indoor location away from direct sunlight.
9. Keep the area 50 cm in front of the feeder clear to ensure unobstructed access for your pet.
10. Ensure there are no obstacles within 50 cm in front, left, and right of the device, and avoid placing it on metal surfaces to ensure proper sensor functionality.
11. Placement near metal or electrical appliances is usually fine. If the feeder doesn't work properly, try moving it further away from the appliance.
12. Clean leftover food particles or debris around the bowl after feeding to prevent lid closure issues and deter pests and bacteria.

## 09 / Warranty Terms

---

Within the period of warranty, if the product fails with no fault of user operations, it will be repaired at Petoneer's expense. The warranty will not cover product failure in examples below:

- 1). Intentional damage to the product by the user or third party
- 2). Failure to operate or maintain the product following the (QIG) Quick Installation Guide Instructions.
- 3). Failure by natural wear and tear including but not limited to scratching, corrosion, oxidation and rusting.
- 4). Failure by non-authorized repair of the product including but not limited to user's own or third-party repairing attempts or modifications.

(All Pictures shown in the manual are for illustration purpose only. Actual product may vary due to product enhancement.)

### FCC Instructions :

This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications not expressly approved by the party responsible for compliance could avoid the user's authority to operate the product.

## FCC Radiation Exposure Statement:

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

### Environmental Conditions

Operating Temperature: 32°F to 104°F, (0 °C to 40 °C) (indoor only)

SkyRC Technology Co., Ltd. declares that this Petoneer NutriCare Feeder (PF009), is in compliance with the essential requirements and other relevant provisions of the Radio Equipment Directive

(2014/53/EU).

### Environment friendly disposal

You can help protect the environment!

Please remember to respect your local regulations: dispose of nonfunctional electrical equipment with an appropriate waste disposal center.



Manufacturer: SkyRC Technology Co., Ltd.

4, 5, 8 Floors, Building 4, Meitai Science Park, Guanguang Road, Guanlan, Longhua District, Shenzhen, China.

### Read all the instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Do not touch hot surfaces. Use handles.
2. To protect against electric shock do not immerse cord, plug into water or other liquid.
3. Close supervision is necessary when any appliance is used by or near children.
4. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
5. Do not operate any appliance with a damaged cord or plug, should the appliance malfunction, or if it has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair or adjustment.
6. The use of the accessory attachments is not recommended by the appliance manufacturer as it may cause injuries.
7. Do not use outdoors.
8. Do not let the cord hang over edge of table or counter, or touch hot surfaces.
9. Do not place on or near a hot gas or electric burner, or in a heated oven.
10. Always attach plug to appliance first, then plug cord in the wall outlet.

11.Do not use the appliance for other than intended use.

12.WARNING: Never leave the appliance unattended whilst in use.

13.Warning: keep the supply cord away from heating tip and metal enclosure while using.

14.This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instructions concerning use of the appliance by a person responsible for their safety.

15.Children should be supervised to ensure that they do not play with the appliance.

16.If the SUPPLY CORD is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

17.WARNING: This tool must be placed on its stand when not in use.

SAVE THESE INSTRUCTIONS.

The device has been approved for use in EU countries and is therefore provided with the **CE mark**. All necessary documentation is available on the website: [www.electric-collars.com](http://www.electric-collars.com)  
Changes to technical parameters, properties and printing errors reserved.

**Service center and distribution**

Reedog, sro  
Sedmidomky 459/8 101  
00 Prague 10  
Phone: +1 646 980 4569  
Email: [info@electric-collars.eu](mailto:info@electric-collars.eu)