


metabo®

HS 8875



0001	2x	141	118	730	0051	1x	344	163	330	
0002	1x	343	395	320	0052	1x	344	163	390	
0003	1x	343	395	350	0053	7x	141	120	210	
0004	1x	343	395	360	0054	1x	339	133	330	
0005	2x	342	001	180	0055	1x	316	042	690	
0006	1x	316	043	730	0056	1x	344	070	660	
0007	1x	341	704	290	0057	1x	343	391	350	
0008	1x	141	151	940	0058	2x	141	119	780	
0009	18x	141	116	020	0059	1x	141	130	650	
0010	1x	343	395	140	0060	1x	00	338	052	070
0011	1x	343	395	370	0060	1x	18	338	052	070
0012	1x	343	254	530	0060	1x	19	338	052	080
0013	1x	343	050	140	0880	1x	344	130	930	
0014	1x	345	000	160	0881	1x	344	130	560	
0015	1x	342	002	440	1001	1x	338	504	370	
0016	1x	343	395	340						
0017	1x	316	041	370						
0018	1x	341	055	110						
0019	2x	344	092	220						
0020	1x	343	391	540						
0021	1x	316	038	620						
0022	4x	141	152	400						
0023	1x	316	026	700						
0024	2x	141	155	400						
0025	1x	342	050	880						
0026	1x	343	395	430						
0027	1x	343	395	420						
0028	1x	316	039	780						
0029	1x	342	021	590						
0030	1x	316	044	070						
0031	1x	339	132	380						
0032	2x	141	121	710						
0033	1x	339	132	370						
0034	2x	341	055	290						
0035	1x	339	133	450						
0036	1x	316	043	430						
0037	1x	343	406	960						
0038	1x	343	395	210						
0039	1x	141	117	060						
0040	1x	343	362	490						
0041	1x	344	100	970						
0042	1x	00	344	493	080					
0042	1x	18	344	489	600					
0042	1x	19	344	491	140					
0043	1x	311	009	920						
0044	1x	143	112	230						
0045	1x	330	001	910						
0046	1x	310	009	520						
0047	1x	143	113	400						
0048	1x	343	394	860						
0049	1x	343	394	420						
0050	1x	316	027	170						

