



st 8 / HS80



Skizze	Art.Nr.	Benennung	description
1	390 1309 011	Schalter	switch
2	390 1309 012		
3	390 1309 013	Schalterboxabdeckung	switch box cover
4	390 1309 014	Überlastschutz	overload protection
5	390 1309 015		
6	390 1309 016		
7	390 1309 017		
8	390 1309 018		
9	390 1309 019	Schalterbox	switch box
10	390 1309 020		
11	390 1309 021	Drehgriff	handle
12	390 1309 022		
13	390 1309 023		
14	390 1309 024		
15	390 1309 025		
16	390 1309 026		
17	390 1309 027		
18	390 1309 028		
19	390 1309 029		
20	390 1309 030		
21	390 1309 031		
22	390 1309 032		
23	390 1309 033		
24	390 1309 034		
25	390 1309 035		
26	390 1309 036	Haken	hook
27	390 1309 037		
28	390 1309 038		
29	390 1309 039		
30	390 1309 040		
31	390 1309 041		
32	390 1309 042		
33	390 1309 043	Zeiger	pointer
34	390 1309 044		
35	390 1309 045		
36	390 1309 046	Gummifuß	rubber foot
37	390 1309 047		
38	390 1309 048		
39	390 1309 049		
40	390 1309 050		
41	390 1309 051		
42	390 1309 052		
43	390 1309 053	Zahnstange	rack
44	390 1309 054		
45	390 1309 055		
46	390 1309 056	Gummifuß	rubber foot
47	390 1309 057		
48	390 1309 058	Skala	scale

49	390 1309 059	Drehgriff	handle
50	390 1309 060	Handrad	handle wheel
51	390 1309 061		
52	390 1309 062		
53	390 1309 063	Stange	rod
54	390 1309 064		
55	390 1309 065		
56	390 1309 066		
57	390 1309 067		
58	390 1309 068		
59	390 1309 069		
60	390 1309 070		
61	390 1309 071		
62	390 1309 072		
63	390 1309 073		
64	390 1309 074		
65	390 1309 075		
66	390 1309 076	Platte	plate
67	390 1309 077		
68	390 1309 078		
69	390 1309 079	Mutter	nut
70	390 1309 080		
71	390 1309 081		
72	390 1309 082		
73	390 1309 083		
74	390 1309 084		
75	390 1309 085		
76	390 1309 086	Überwurfmutter	cap nut
77	390 1309 087	Absaugstutzen	dust outlet
78	390 1309 088		
79	390 1309 089		
80	390 1309 090		
81	390 1309 091		
82	390 1309 092	Tischeinlage	table insert
83	390 1309 093	Skala	scale
84	390 1309 094		
85	390 1309 095		
86	390 1309 096		
87	390 1309 097		
88	390 1309 098		
89	390 1309 099		
90	390 1309 100		
91	390 1309 101		
92	390 1309 102		
93	390 1309 103		
94	390 1309 104		
95	390 1309 105		
96	390 1309 106	Mutter	nut
97	390 1309 107	äußerer Sägeblattflansch	outer sawblade flange
98	390 1208 701	Sägeblatt Ø210 z24 WZ	Sawblade Ø210 z24 WZ
99	390 1309 109	innerer Sägeblattflansch	inner sawblade flange
100	390 1309 110		
101	390 1309 111		
102	390 1309 112	ložisko 6200	
103	390 1309 113		

104	390 1309 114	ložisko 608	
105	390 1309 115		
106	390 1309 116		
107	390 1309 117		
108	390 1309 118		
109	390 1309 119		
110	390 1309 120	Kohlebürsten (Satz = 2 Stück)	carbon brushes (set = 2 pcs.)
111	390 1309 121		
112	390 1309 122		
113	390 1309 123		
114	390 1309 124		
115	390 1309 125		
116	390 1309 126		
117	390 1309 127	Feder	spring
118	390 1309 128		
119	390 1309 129		
120	390 1309 130		
121	390 1309 131	Halterung	holder
122	390 1309 132		
123	390 1309 133		
124	390 1309 134		
125	390 1309 135	Schraube	screw
126	390 1309 136		
127	390 1309 137		
128	390 1309 138		
129	390 1309 139		
130	390 1309 140		
131	390 1309 141		
132	390 1309 142		
133	390 1309 143		
134	390 1309 144		
135	390 1309 145		
136	390 1309 146		
137	390 1309 147		
138	390 1309 148		
139	390 1309 149		
140	390 1309 150		
141	390 1309 151		
142	390 1309 152		
102-112, 40, 60	390 1309 010	Motor kpl.	motor cpl.
10, 17, 78-80	390 1309 153	Sägeblattschutz kpl.	saw blade guard cpl.
11-19, 25	390 1309 154	Längsansschlag kpl.	fence cpl.
17, 20-24, 128-129	390 1309 155	Querschneidlehre kpl.	mitre gauge cpl.
	390 1309 156	Beipackbeutel	screw bag