



<b>RAT 3620i</b>			
<b>Pozice</b>	<b>Obj.číslo</b>	<b>Popis</b>	<b>Počet</b>
1	RAT3620i-01	blade assembly (right)	1
2	RAT3620i-02	screw bolt	2
3	RAT3620i-03	blade assembly (left)	1
4	RAT3620i-04	Locknut	2
6	RAT3620i-06	screw	26
7	RAT3620i-07	guard plate	1
8	RAT3620i-08	chassis base	1
9	RAT3620i-09	safe lock complete	1
10	RAT3620i-10	Safety lock block complete	1
11	RAT3620i-11	main housing	1
12	RAT3620i-12	Cable fix board	1
13	RAT3620i-13	screw	31
14	RAT3620i-14	Decorative cover-right	1
15	RAT3620i-15	Transparent cover	1
16	RAT3620i-16	Shield torsional spring	1
17	RAT3620i-17	set pin	2
18	RAT3620i-18	main housing	1
19	RAT3620i-19	Decorative cover-left	1
20	RAT3620i-20	connection shaft	1
21	RAT3620i-21	No.1 Sponge	1
22	RAT3620i-22	knob	4
23	RAT3620i-23	coach screw	4
24	RAT3620i-24	No.2 rod	2
25	RAT3620i-25	New S-shaped clamp	2
26	RAT3620i-26	No. 1 rod complete	1
27	RAT3620i-27	Locknut	6
28	RAT3620i-28	φ6 wave washer	6
29	RAT3620i-29	coach screw	4
30	RAT3620i-30	screw	2
32	RAT3620i-32	wheel cover	2
33	RAT3620i-33	R pin	2
34	RAT3620i-34	φ10 flat key	2
35	RAT3620i-35	wheels	2
36	RAT3620i-36	φ6 washer	1
37	RAT3620i-37	wheel holder assembly	1
38	RAT3620i-38	Release ring	1
39	RAT3620i-39	wheel adjust bracket	1
40	RAT3620i-40	iron wheel adjust spring	1
41	RAT3620i-41	iron wheel adjust shaft	1
42	RAT3620i-42	screw	2
43	RAT3620i-43	button	1
44	RAT3620i-44	handle button spring	2
100	RAT3620i-100	Gear box assembly	1
101		gear box right	1
102		sealing ring baffle	2
103		sealing ring	2
104		bearing	2
105		washer	2
106		worm gear shaft	1
107		flat key	1
108		worm gear	1
109		bearing	1

110		worm gear	1
111		gearbox sealing strip	1
112		Gear box left	1
113		"O" ring	1
114		screw	1
115		screw with gasket	8
116		Sealing ring	1
117		splined hub	2
118		bearing	1
119		thrust bearing	1
120		axle sleeve	1
200	RAT3620i-200	Motor assembly	1
201		gear box cover	1
202		bearing	1
203		gear shaft	1
204		flat key	1
205		spring washer	1
206		rack wheel	1
207		screw	4
208		bearing	1
209		gear case	1
210		pinion	1
211		DC motor	1
300	RAT3620i-300	H shape switch assembly	1
301		main handle left	1
302	RAT3620i-302	trigger spring	1
303	RAT3620i-303	trigger	1
305	RAT3620i-305	switch button	1
306		main housing right	1
307	RAT3620i-307	No. 3 rod	1
308		handle press plate	1
310		secondary handle right	1
311		secondary handle left	1
312		chock plug	1
313		Conncet power cord	1
314		screw	2
315	RAT3620i-315	DC rocker switch	1
316		screw	1
400	RAT3620i-400	Battery pack assembly	1
401		Board - right	1
402		Small pin board	2
403		pressing plate	2
404		screw	4
405		Board - left	1
406			1