






RPPW 207 SET			
Pozice	Obj.číslo	Popis	Počet
1	RPPW207SET-1	lance for spray gun	1
2	RPPW207SET-2	M8 flange nut	1
3	RPPW207SET-3	L type screw cover	1
4	RPPW207SET-4	L type screw	1
5	RPPW207SET-5	M8 flange nut	1
6	RPPW207SET-6	Frame below	1
7	RPPW207SET-7	Soap bottle	1
8	RPPW207SET-8	Soap bottle cover	1
9	RPPW207SET-9	cross screw M6X45	2
10	RPPW207SET-10	Washer	2
11	RPPW207SET-11	M6 nut	2
12	RPPW207SET-12	Abrosber for frame below	2
13	RPPW207SET-13	cross screw M6X35	2
14	RPPW207SET-14	Frame middle	1
15	RPPW207SET-15	Bolt M8*35	4
16	RPPW207SET-16	Bolt M8*20	4
17	RPPW207SET-17	Abrosber for engine	4
18	RPPW207SET-18	screw M8	8
19	RPPW207SET-19	screw M8	2
20	RPPW207SET-20	washer	4
21	RPPW207SET-21	shaft	2
22	RPPW207SET-22	wheel	2
23	RPPW207SET-23	Frame	2
24	RPPW207SET-24	soap bottle suction hose	1
25	RPPW207SET-25	hoodle	4
26	RPPW207SET-26	pump	1
27	RPPW207SET-27	cap nut M6	6
28	RPPW207SET-28	cross screw M6X40	4
29	RPPW207SET-29	cross screw ST4.8X20	3
30	RPPW207SET-30	plastic	1
31	RPPW207SET-31	plastic nozzle rubber cover	4
32	RPPW207SET-32	4pcs nozzle	4
33	RPPW207SET-33	handle	1
34	RPPW207SET-34	the protect handle cover	1
35	RPPW207SET-35	plastic panel	1
36	RPPW207SET-36	gun rack	1
37	RPPW207SET-37	gun grio	1
38	RPPW207SET-38	complete engine	1
39	RPPW207SET-39	high pressure hose	1
40	RPPW207SET-40	water inlet connector	1




Pozice	Obj.číslo	Popis	Počet
1	RPPW207P-1	Pump body assy	1
2	RPPW207P-2	Pump body	1
3	RPPW207P-3	Plunger oil seal 12x20x5	1
4	RPPW207P-4	Oil seal bracket	1
5	RPPW207P-5	Plunger	1
6	RPPW207P-6	Plunger plate	1
7	RPPW207P-7	Plunger spring	1
8	RPPW207P-8	O ring 9X2.4/70HS/ROHS	1
9	RPPW207P-9	Special-shaped seal	1
10	RPPW207P-10	P202 Pump cover assy	1
11	RPPW207P-11	Brass pump cover	1
12	RPPW207P-12	Cap G1/8	1
13	RPPW207P-13	Thermo valve G1/8-63	1
14	RPPW207P-14	Thermo valve cover	1
15	RPPW207P-15	Checking valve assy	1
16	RPPW207P-16	Checking valve cap assy	1
17	RPPW207P-17	O ring 11X2/80HS/ROHS	1
18	RPPW207P-18	Water seal seat &Water seal assy	1
19	RPPW207P-19	Water seal gasket	1
20	RPPW207P-20	Water seal 12X20X5-2400PSI	1
21	RPPW207P-21	Water seal 12X20X4	1
22	RPPW207P-22	O ring 22X1_5/70HS/ROHS	1
23	RPPW207P-23	O ring 4.8X1.8/80HS/ROHS	1
24	RPPW207P-24	Siphon nozzle assy	1
25	RPPW207P-25	Relief valve assy	1
26	RPPW207P-26	Back pressure valve seat	1
27	RPPW207P-27	Back pressure valve assy	1
28	RPPW207P-28	Outlet tube assy &Outlet connector	1
29	RPPW207P-29	O ring 8X2/80HS/ROHS	1
30	RPPW207P-30	O ring 13.2X2/80HS/ROHS	1
31	RPPW207P-31	Inlet tube&Inlet connector	1
32	RPPW207P-32	O ring 14X2.65/70HS/ROHS	1
33	RPPW207P-33	Oil cylinder assy	1
34	RPPW207P-34	Oil cylinder	1
35	RPPW207P-35	Checking valve cap	1
36	RPPW207P-36	O ring 11X2/80HS/ROHS	1
37	RPPW207P-37	Bearing 42	1
38	RPPW207P-38	Oil seal 52*35*8	1
39	RPPW207P-39	Swash plate	1
40	RPPW207P-40	Bearing 25	1
41	RPPW207P-41	Flat key	1
42	RPPW207P-42	Bolt M8*45	1
43	RPPW207P-43	Bolt M8*30	1
44	RPPW207P-44	Gasket 8	1

45	RPPW207P-45	Bolt M8X35	1
----	-------------	------------	---


Pozice	Obj.číslo	Popis
1.1	RPPW207E-1.1	Head Comp,Cylinder
1.2	RPPW207E-1.2	Bolt,Stud,Ex M6x110
1.3	RPPW207E-1.3	Pin,Dowel 10x16
1.4	RPPW207E-1.4	Gasket,Cylinder
1.5	RPPW207E-1.5	Bolt,Stud,Ex M8x32
1.6	RPPW207E-1.6	Plug,Spark
1.7	RPPW207E-1.7	Bolt,Flange M8x55
1.8	RPPW207E-1.8	Packing,Head Cover
1.9	RPPW207E-1.9	Cover Comp,Head
1.10	RPPW207E-1.10	Bolt,Flange M6x12
1.11	RPPW207E-1.11	Tube,Breather




2.1	RPPW207E-2.1	Crank Case
2.2	RPPW207E-2.2	Oil Seal 25x41.25x6
2.3	RPPW207E-2.3	Washer,Drain Plug 10x16x1.5
2.4	RPPW207E-2.4	Bolt,Drain Plug M10x1.25-15
2.5	RPPW207E-2.5	Alart Unit,Oil
2.6	RPPW207E-2.6	Bolt,Flange M6x12
2.7	RPPW207E-2.7	Oil Level Switch
2.8	RPPW207E-2.8	Bolt,Flange M6x12
2.9	RPPW207E-2.9	Governor Gear Assy
2.10	RPPW207E-2.10	Governor Gear Washer
2.11	RPPW207E-2.11	Governor Shaft
2.12	RPPW207E-2.12	Governor Shaft Clip
2.13	RPPW207E-2.13	Governor Shaft Sleeve
2.14	RPPW207E-2.14	Bearing,Radial Ball 6205
2.15	RPPW207E-2.15	Washer,Drain Plug 6x15x0.5
2.16	RPPW207E-2.16	Pin Lock
2.17	RPPW207E-2.17	Shaft,Governor Arm




3.1	RPPW207E-3.1	Gauge Assy,Oil Level
3.2	RPPW207E-3.2	Bolt,Flange M8x32
3.3	RPPW207E-3.3	Case Cover
3.4	RPPW207E-3.4	Oil Seal 25x41.25x6
3.5	RPPW207E-3.5	Bearing,Radial Ball 6205
3.6	RPPW207E-3.6	Pin,Dowel 8x14
3.7	RPPW207E-3.7	Packing,Case Cover




4.1	RPPW207E-4.1	Ring Set
4.2	RPPW207E-4.2	Clip,Piston Pin
4.3	RPPW207E-4.3	Piston
4.4	RPPW207E-4.4	Pin,Piston
4.5	RPPW207E-4.5	Rod Assy,Connecting
4.6	RPPW207E-4.6	Key
4.7	RPPW207E-4.7	Crankshaft Comp



5.1	RPPW207E-5.1	Arm,Comp
5.2	RPPW207E-5.2	Nut,Pivot Adjusting
5.3	RPPW207E-5.3	Pivot,Rocker Arm
5.4	RPPW207E-5.4	Arm,Valve Rocker
5.5	RPPW207E-5.5	Bolt,Pivot Arm
5.6	RPPW207E-5.6	Plate,Push Rod Guide
5.7	RPPW207E-5.7	Rod,Push
5.8	RPPW207E-5.8	Lifter,Valve
5.9	RPPW207E-5.9	Ratator ,Valve
5.10	RPPW207E-5.10	Retainer,Valve Spring
5.11	RPPW207E-5.11	Spring,Valve
5.12	RPPW207E-5.12	Oil Seal,Valve
5.13	RPPW207E-5.13	Valve Comp,
5.14	RPPW207E-5.14	Valve Comp,
5.15	RPPW207E-5.15	Camshaft Assy





6.1	RPPW207E-6.1	Switch Assy,Engine Stop
6.2	RPPW207E-6.2	Cover ,Fan
6.3	RPPW207E-6.3	Bolt,Flange M6x12
6.4	RPPW207E-6.4	Reel,Recoil Starter Component
6.5	RPPW207E-6.5	Screw,Setting
6.6	RPPW207E-6.6	Guide,Ratchet
6.7	RPPW207E-6.7	Spring,Fristion
6.8	RPPW207E-6.8	Ratchet,Starter
6.9	RPPW207E-6.9	Spring,Return
6.10	RPPW207E-6.10	Reel,Recoil Starter
6.11	RPPW207E-6.11	Spring,Recoil Starter
6.12	RPPW207E-6.12	Rope </td
6.13	RPPW207E-6.13	Knob,Recoil Starter
6.14	RPPW207E-6.14	Cover Comp,Fan
6.15	RPPW207E-6.15	Bolt,Flange M6x7




7.1	RPPW207E-7.1	Bolt,Flange M6x12
7.2	RPPW207E-7.2	Shroud Comp
7.3	RPPW207E-7.3	Plate,Side
7.4	RPPW207E-7.4	Cilp,Harness
7.5	RPPW207E-7.5	Bolt,Flange M6x22

8.1	RPPW207E-8.1	Packing,Carburetor
8.2	RPPW207E-8.2	Insulator,Carburetor
8.3	RPPW207E-8.3	Carburetor
8.4	RPPW207E-8.4	Air Filter Paper
8.5	RPPW207E-8.5	Carburetor Gasket Connection





9.1	RPPW207E-9.1	Flywheel Comp
9.2	RPPW207E-9.2	Coil Assy,Ignition
9.3	RPPW207E-9.3	Bolt,Flange M6x25
9.4	RPPW207E-9.4	Coil Assy,Charge
9.5	RPPW207E-9.5	Bolt,Flange M6x25
9.6	RPPW207E-9.6	Clamper,Cord
9.7	RPPW207E-9.7	Bolt,Flange M6x12
9.8	RPPW207E-9.8	Fan,Cooling
9.9	RPPW207E-9.9	Pulley,Starter
9.10	RPPW207E-9.10	Nut,Special

10.1	RPPW207E-10.1	Starter Motor
10.2	RPPW207E-10.2	Bolt,Flange M6x25
10.3	RPPW207E-10.3	Pin,Dowel 8x12



11.1	RPPW207E-11.1	Control Assy
11.2	RPPW207E-11.2	Bolt,Flange M6x12
11.3	RPPW207E-11.3	Spring,Governor
11.4	RPPW207E-11.4	Rod,Governor
11.5	RPPW207E-11.5	Spring,Throttle Return
11.6	RPPW207E-11.6	Arm,Governor
11.7	RPPW207E-11.7	Bolt,Quadrate Head
11.8	RPPW207E-11.8	Nut,Flange M6



12.1	RPPW207E-12.1	Air Cleaner Assy
12.1.1	RPPW207E-12.1.1	Seat Air Filter
12.1.2	RPPW207E-12.1.2	Element Air Filter
12.1.3	RPPW207E-12.1.3	Cover Air Filter
12.2	RPPW207E-12.2	Nut,Flange M6

