



RPS 7058

od roku výroby 2023



RPS 7058 Machine - r.v.2023			
Pozice	Obj.číslo	Popis	Množství
1	RPS7058-V2-1	Bracket 1	1
2	RPS7058-V2-2	Shock-absorbing pads	2
3	RPS7058-V2-3	Limit plates	2
4	RPS7058-V2-4	Bolt M4 x 65	4
5	RPS7058-V2-5	Gasket 4	4
6	RPS7058-V2-6	Springpad M4	4
7	RPS7058-V2-7	Nut M4	4
8	RPS7058-V2-8	Handrails	1
9	RPS7058-V2-9	Switch	1
10	RPS7058-V2-10	Bolt M8 x 40	6
11	RPS7058-V2-11	Nut M8	6
12	RPS7058-V2-12	Gasket 8	15
13	RPS7058-V2-13	Springpad M8	18
14	RPS7058-V2-14	PVC Baffle	1
15	RPS7058-V2-15	Platen	1
16	RPS7058-V2-16	Feed hopper	1
17	RPS7058-V2-17	Cover	1
18	RPS7058-V2-18	Bolt M6 x 14	10
19	RPS7058-V2-19	Nut M6	12
20	RPS7058-V2-20	Gasket 6	12
21	RPS7058-V2-21	Gasoline engine DHP212	1
22	RPS7058-V2-22	Cushion blocks	1
23	RPS7058-V2-23	Dowel pins M10x20	1
24	RPS7058-V2-24	Bolt M8x80	1
25	RPS7058-V2-25	Scrap chamber	1
26	RPS7058-V2-26	Discharge hopper	1
27	RPS7058-V2-27	Square neck bolts M6x16	2
28	RPS7058-V2-28	Outlet	1
29	RPS7058-V2-29	Discharge hopper baffle	1
30	RPS7058-V2-30	Bolt M8 x 16	9
31	RPS7058-V2-31	Blade seat	1
32	RPS7058-V2-32	Cutterhead	1
33	RPS7058-V2-33	Cover	1
34	RPS7058-V2-34	Flat washer 8	3
35	RPS7058-V2-35	Bolt M8x25	7
36	RPS7058-V2-36	Blade	2
37	RPS7058-V2-37	Wheel	2
38	RPS7058-V2-38	Bracket 2	1
39	RPS7058-V2-39	Bolt	6
40	RPS7058-V2-40	Bolt	4
41	RPS7058-V2-41	Allen socket bolts M10*20	2



RPS 7058 Engine - r.v.2023			
Pozice	Obj.číslo	Popis	Množství
1	342013	Cylinder Head	1
2	314501	Starter Pully	1
3	97109	Spark Pulg	1
4	342081-010	Fuel Tank	1
5	342018	Intake Valve	1
6	342015	Exhaust Valve	1
7	240801	Clip	1
8	342022	Piston Ring Assembly	1
9	93507	Crankcase Oil Seal	2
10	242701	Throttle Lever	1
11	243902	Retaining Clip	1
12	244207	Spring C	1
13	94403	Fuel Hose Clip	1
14	342035	Spring B	1
15	342067	Valve Spring	2
16	243604	Fuel Cap	1
17	241806	Valve Seal	1
18	97515	Ignitor	1
19	96810	Fuel Tank Gasket	2
20	94223	Washer,Crankshaft	1
21	342085	Air Filter Assembly	1
22	244001	Speed Regulating Arm	1
23	342026	Cylinder Head Cover	1
24	342034	Shroud	1
25	342068	Speed Controller	1
26	342077	Wind-Lead-Cover	1
27	245601-138	Dipstick Assembly	2
28	342025	Carburetor Connection Block	1
29	241802	Exhaust Valve Spring Seat	2
30	342002	Rocking Arm Shaft	2
31	342000	Rocking Arm	2
32	342001	Rocker Shaft Fixing Bracket	1
33	342028	Push Rod	2
34	342006	Valve Lifter	2
35	243901	Racking Bar	1
36	241804	Top Cap	2
37	244601	Impeller	1
38	96051	Gasket	1
39	95672	Blast Pipe	1
40	95434	Fuel Hose	1
41	245104	Oil Protector	1
42	342083	Crankshaft	1
43	244302	Centrifugal Governor Gear Assembly	1
44	96055	Exhaust Seal Washer	1
45	94229	Air Filter Gasket	1
46	96313	Intake Gasket	1

47	96312	Cylinder Head Cover Seal Washer	1
48	96310	Crankcase Seal Washer	1
49	96311	Cylinder Head Gasket	1
50	342023	Piston	1
51	342021	Piston Pin	1
52	342020	Piston Pin Ring	2
53	342016	Connecting Rod Assembly	1
54	96804	Swinging Rod Gasket	1
55	90079	Nut M8	2
56	240904	Crankcase Locating Pin	2
57	240905	Cylinder Head Locating Pin	2
58	90003	Flywheel Nut M14*1.5	1
59	90035	Nut M6	2
60	91007	Air Exhaust Stud Stud Bolt M8*38	2
61	91006	Air Inlet Stud Stud Bolt M6*111	2
62	91325	Bolt M6X12	12
63	91331	Bolt M6X25	2
64	91359	Bolt M8X60	4
65	91816	Oil Drain Bolt	2
66	94007	Oil Drain Bolt Washer	2
67	342088	Muffler	1
68	342084-010	Starter Assembly	1
69	94206	Spring Washer Ø8	2
70	91329	Bolt M6X16	4
71	91347	Bolt M6X16	6
72	240401	Flywheel	1
73	91333	Bolt M6X28	1
74	342005	Camshaft Assembly	1
75	342011	Crankcase	1
76	342012	Crankcase Cover	1
77	94423	Fuel Hose Clip	1
78	342075	Carburetor Assembly	1
79	342019	Oil Sensor Assembly	1
80	93009	Bearing	2
81	90038	Nut M6	2
82	245205	Ignition Switch	1
83	246501	Crankshaft Flat Key	1