




RABC 2620i SET			
Pozice	Obj.číslo	Popis	Počet
2	RABC2620iSET-02	Battery pack left cabin	1
3	RABC2620iSET-03	Pole seat	2
4	RABC2620iSET-04	Connecting cable	1
5	RABC2620iSET-05	Battery pack lower supporter	1
6	RABC2620iSET-06	Battery pack upper supporter	1
7	RABC2620iSET-07	Battery pack right housing	1
8	RABC2620iSET-08	Screw	16
9	RABC2620iSET-09	PCBA left supporter	1
10	RABC2620iSET-10	PCBA	1
11	RABC2620iSET-11	PCBA right supporter	1
12	RABC2620iSET-12	Left handle 2	1
13	RABC2620iSET-13	Right handle 2	1
14	RABC2620iSET-14	Hex nut	3
15	RABC2620iSET-15	Left handle 1	1
16	RABC2620iSET-16	Side handle	1
17	RABC2620iSET-17	Lock button	1
18	RABC2620iSET-18	Lock button spring	1
19	RABC2620iSET-19	Right handle 1	1
20	RABC2620iSET-20	Plug	1
21	RABC2620iSET-21	Lower tube	1
22	RABC2620iSET-22	Hex rod	3
23	RABC2620iSET-23	Hex rod	8
24	RABC2620iSET-24	Motor shelf	1
25	RABC2620iSET-25	Bearing	1
26	RABC2620iSET-26	Rotor	1
27	RABC2620iSET-27	Stator	1
28	RABC2620iSET-28	Bearing	1
29	RABC2620iSET-29	Screw	2
30	RABC2620iSET-30	Gasket	2
31	RABC2620iSET-31	Motor cover	1
32	RABC2620iSET-32	Hex rod	3
33	RABC2620iSET-33	Lower press plate	1
34	RABC2620iSET-34	Lock nut	1
35	RABC2620iSET-35	Press chuck	1
36	RABC2620iSET-36	Blade	1
37	RABC2620iSET-37	Locate button	1
38	RABC2620iSET-38	Circlip	1
39	RABC2620iSET-39	Spring	1
40	RABC2620iSET-40	Hex rod	4
41	RABC2620iSET-41	Protector	1
42	RABC2620iSET-42	Blade	1
43	RABC2620iSET-43	Screw	2
44	RABC2620iSET-44	String head assembly	1
45	RABC2620iSET-45	Hex nut	1
46	RABC2620iSET-46	Knob	1
47	RABC2620iSET-47	Middle connector	1
48	RABC2620iSET-48	Plug	1
49	RABC2620iSET-49	Strap	1
50	RABC2620iSET-50	Hook	1
51	RABC2620iSET-51	Strap moving bucket	1
52	RABC2620iSET-52	Hex rod	1
53	RABC2620iSET-53	Strap fixed bucket	1

54	RABC2620iSET-54	Lower tube	1
55	RABC2620iSET-55	Tube base lower cap	1
56	RABC2620iSET-56	Soft gasket	1
57	RABC2620iSET-57	Tube base	1
58	RABC2620iSET-58	Base top cover	1
59	RABC2620iSET-59	Switch connecting cable	2
60	RABC2620iSET-60	Wave shape tube	1
61	RABC2620iSET-61	Switch	1
62	RABC2620iSET-62	Screw	2
63	RABC2620iSET-63	Trosion spring	1
64	RABC2620iSET-64	Switch trigger	1