


# VeGA GK5500W 2022


## E01 CYLINDER SPARK

No.	ID Zboží	Název
E01-1	G1214E0201000	HEAD SUBASSEMBLY, CYLINDER
E01-2	G9103E0202010	STUD
E01-3	G910308034010	STUD
E01-4	G905108012000	PIN
E01-5	G1230E0201000	GASKET, CYLINDER HEAD
E01-6	G1241E0201010	COVER SUBASSEMBLY, CYLINDER HEAD
E01-7	G1204E0201000	GASKET, CYLINDER HEAD COVER
E01-8	G1703E0202000	TUBE, BREATHER
E01-9	G1247E0201010	
E01-10	G1567E0101000	PLUG, SPARK
E01-11	G910110080010	BOLT, CYLINDER HEAD




### E02 CRANKCASE

No.	ID Zboží	Název
E02-1	G1131E0904000	CRANKCASE SUBASSEMBLY.
E02-2	G9065E0201000	SEAL, OIL
E02-3	G9041E0201010	WASHER
E02-4	G910112015010	BOLT, DRAIN PLUG
E02-5	G1526E0101000	OIL SENSER
E02-6	G900106012010	BOLT
E02-7	G905462026000	BEARING
E02-8	G1536E0201000	
E02-9	G900106014010	BOLT
E02-10	G9041E0202000	WASHER
E02-11	G1607E0201000	ARM, GOVERNOR
E02-12	G9065E0202000	SEAL, OIL
E02-13	G9052E0101000	PIN




**E03 CRANKCASE / GOVERNOR**

No.	ID Zboží	Název
E03-1	G1141E0203000	COVER, CRANKCASE
E03-2	G1101E0201000	GASKET, CRANKCASE
E03-3	G905462026000	BEARING
E03-4	G1503E0201110	DIPSTICK SUBASSEMBLY, OIL
E03-5	G9065E0202000	SEAL, OIL
E03-6	G905112020000	PIN
E03-7	G900108040010	BOLT
E03-8	G905462076000	BEARING
E03-9	G1660E0201000	GEAR ASSY, GOVERNOR




**E04 ROD,CRANKSHAFT CONNETING**

No.	ID Zboží	Název
E04-1	G1330E0902000	CRANKSHAFT ASSY.
E04-2	G1340E0901000	BALANCE AXIS ASSY.




**E05 RING SET, CRANKSHAFT CONNECTING**

No.	ID Zboží	Název
E05-1	G1320E0901000	RING, THE FIRST
E05-2	G1313E0201000	CLIP, PISTON PIN
E05-3	G1311E0901000	PISTON
E05-4	G1312E0201000	PIN, PISTON
E05-5	G1301E0901000	ROD, CONNECTING




**E06 TRAIN, VALVE, CAMSHAFT**

No.	ID Zboží	Název
E06-1	G1420E0901000	CAMSHAFT ASSY.
E06-2	G1220E0201000	VALVE, EXHAUST
E06-3	G1211E0201000	GUIDE, SEAL
E06-4	G1213E0201000	SPRING, VALVE
E06-5	G1212E0201000	SEAT, VALVE SPRING
E06-6	G1209E0201000	LOCKER, VALVE
E06-7	G1481E0201000	TAPPET, VALVE
E06-8	G1470E0201000	LIFTER, VALVE
E06-9	G1409E0201000	PLATE SUBASSEMBLY, LIFTER STOPPER
E06-10	G9103E0101040	BOLT, VALVE ADJUSTING
E06-11	G1431E0201000	ROCKER, VALVE
E06-12	G1410E0101040	NUT, VALVE ADJUSTING
E06-13	G1411E0101000	NUT, VALVE LOCK
E06-14	G1208E0201000	VALVE SEAT



E07 STARTER, RECOIL		
No.	ID Zboží	Název
E07-1	G2810E0202H22	Hand start components
E07-2	G1930E0201010	Cylinder air guide
E07-3	G900106012010	Standard Hex Flange Bolts (Small Head)






**E08 CARBURETOR**


No.	ID Zboží	Název
E08-1	G1610E0205030	CARBURETOR ASSY.
E08-2	G1701E0201000	GASKET, AIR CLEANER
E08-3	G1601E0201000	GASKET, CARBURETOR
E08-4	G1603E0201000	PLATE, CARBURETOR INSULATOR
E08-5	G1702E0201000	GASKET, INLET






**E09 CLEANER, AIR**

No.	ID Zboží	Název
F09-1	G1710E0202000	CLEANER, AIR
F09-2	G900408000010	NUT




**F10 MUFFLER ASSY.**

No.	ID Zboží	Název
F10-1	G1810G0201000	MUFFLER ASSY
F10-2	G2811G0201000	Wind shield
F10-3	G3013G0201010	muffler bracket
F10-4	G1801E0201000	GASKET, EXHAUST OUTLET
F10-5	G900508000010	NUT
F10-6	G900106012040	Standard Hex Flange Bolts (Small Head)
F10-7	G900108016040	Standard Hex Flange Bolts (Small Head)




#### F11 TANK ASSY, FUEL

No.	ID Zboží	Název
F11-1	G1679G0601110	TANK, FUEL
F11-2	G3002G0101000	Oil switch parts
F11-3	G9068E0103000	TUBE, FUEL
F11-4	G1685G0101040	FUEL TANK CAP
F11-5	G1696G0101000	STRAINER, FUEL
F11-6	G3601G0201000	Oil standard parts
F11-7	G900805012040	Cross recessed countersunk head screws
F11-8	G900106025040	BOLT
F11-9	G904106000040	Flat Washers - Grade A
F11-10	G9069G0101010	bushing
F11-11	G3001G0101000	Fuel tank support sleeve




**F12 FLYWHEEL, STARTER PULLEY**

No.	ID Zboží	Název
E12-1	G910216000010	NUT, FLYWHEEL
E12-2	G2802E0201000	PULLEY, STARTER
E12-3	G1935E0201000	IMPELLER
E12-4	G1351E0201000	FLYWHEEL SUBASSEMBLY
E12-5	G1506E0201000	COIL, IGNITION
E12-6	G900106028010	BOLT




### F13 CONTROL ASSY., THROTTLE

No.	ID Zboží	Název
E13-1	G1668E0201010	CONTROL ASSY, THROTTLE
E13-2	G900106012010	BOLT
E13-3	G1606E0202000	SPRING, GOVERNOR
E13-4	G1608E0201010	SUPPORT SUBASSEMBLY, GOVERNOR
E13-5	G910106021010	BOLT, GOVERNOR SUPPORT
E13-6	G900408000011	NUT
E13-7	G1605E0201010	ROD, GOVERNEOR
E13-8	G1604E0201030	SPRING, THROTTLE VALVE RETURNING




E14 FRAME ENGINE		
No.	ID Zboží	Název
E14-1	G3616G0618H20	FRAME ASSY, ENGINE
E14-2	G3618G0603H20	handlebar combination
E14-3	G910408075040	Hexagon socket head cap screws
E14-4	G363508000040	nylon nut
E14-6	G3001G0501000	Fuel tank support sleeve
E14-7	G900410000011	Hexagon flange face nuts (with anti-skid teeth)
E14-8	G3610G0201000	Rack shock pad
E14-9	G900412000040	Hexagon flange face nuts (without anti-skid teeth)
E14-10	G9041G1401040	Flat Washers - Grade A
E14-11	G3633G0603000	front wheel
E14-12	G3631G0602080	axle
E14-13	G900408000011	Hexagon flange face nuts (with anti-skid teeth)
E14-14	G3614G0601H20	Rack shock mount bracket
E14-15	G900108016040	Standard Hex Flange Bolts (Small Head)
E14-16	G900106016040	Standard Hex Flange Bolts (Small Head)
E14-17	G900408000041	Hexagon flange face nuts (with anti-skid teeth)
E14-18	G3613G0501000	Rack shock mount



#### E14 PANEL ASSY., CONTROL


No.	ID Zboží	Název
E14-1	G3590G0501000	SEAT, PANEL
E14-2	G3634G0502000	Board ,Panel
E14-3	G3634G0501000	Board ,Panel
E14-4	G3570G0512H20	PANEL , CONTROL
E14-5	G9011G0101010	Scew
E14-6	G900106016040	BOLT
E14-7	G900406000041	NUT
E14-8	G900404000011	NUT





#### E15 PANEL ASSY, CONTROL

No.	ID Zboží	Název
E15-1	G3590G0601000	SEAT, PANEL
E15-2	G3634G0502000	Decorative plates
E15-3	G3634G0501000	Decorative plates
E15-4	G3570G0601H20	PANEL , CONTROL
E15-5	G9011G0101010	Screw
E15-6	G900106016040	BOLT
E15-7	G900406000041	NUT
E15-8	G900404000011	NUT



#### E16 MOTOR

No.	ID Zboží	Název
E16-1	G3130G0202000	MOTOR ASSY
E16-4	G3021G0201000	BRACKET, MOTOR
E16-5	G910106190010	BOLT
E16-6	G9041G0701010	WASHER
E16-7	G910110275010	BOLT
E16-8	G3060G0201000	REGULATOR, VOLTAGE
E16-9	G900105016010	BOLT
E16-10	G3307G0101000	Carbon brush combination
E16-11	G900105016010	BOLT
E16-12	G3022G0201H20	COVER, MOTOR TAIL
E16-13	G900105010040	BOLT
E16-14	G3594G0101000	Wiring board
E16-15	G900105016010	BOLT
E16-16	G9072G0101000	BANDAGE
E16-17	G900105016010	BOLT
E16-18	G910105220080	Non-standard bolts (stator fixing bolts)
E16-19	G910205000000	Non-standard nut (stator fixing nut)
E16-20	G904205000080	spring pad