


INSTALLATION OF THE COMPLETE DEVICE

I Install the outlet pipe and the filter tray




7

INSTALLATION OF THE COMPLETE DEVICE


II Connect to the power cord

Please insert the USB power cord port into the socket at the bottom of the main device. (DO NOT connect to the power supply)



PRODUCT USE

III How to add water




8


PRODUCT USE

II Installation of the complete device and use after starting up

1. After filling, put the filter tray, filter and drinking tray in proper order,




2. Connect the USB power port to the power plug, and then plug it into a power socket to start. (* the initial state is Smart mode by default)



9

INDICATOR LIGHT DESCRIPTION



10

MAINTENANCE AND CLEANING

I. Cleaning and Maintenance of Water Storage Barrel

- The water temperature of the device ranges from 0°C to 50°C.
- DO NOT expose it in the sun, so as not to accelerate the yellowing of the machine.
- Please clean the complete machine after disconnecting the power supply, and ensure that the bottom connector is dry.
- Please clean the device in a large-capacity container such as a sink to prevent water from spilling.
- DO NOT use petrol, kerosene, polishing powder, bleach and other chemical reagents to clean the device.
- DO NOT place or soak the device and pump in boiling water.
- For daily maintenance, wipe the surface of the device and power cord to remove stains with a soft cloth rinsed with warm water. (Please power off first)
- It is recommended to completely replace the drinking water every 3-4 days. When replacing, please clean all parts.
- When not used for a long time, please clean the device, put parts into the packing box in the original packaging order after dry, and store them properly in a dry place.

II. Replacement of the Filter

- The filter shall be replaced every 60 days in smart mode (SMART), and every 30 days or so in normal mode (NORMAL). (Specific replacement shall be subject to the filter indicator light.)
- Soak the new filter thoroughly before replacement (it's recommended to soak twice, five minutes each time) and rinse slightly before replacing.
- For the sake of your pets' health, please replace the filter frequently according to the use of the filter element.

11

MAINTENANCE AND CLEANING

III. Cleaning of the Silent Pump

- The CNC silent pump shall be cleaned every week to prevent dirt from clogging the waterway, resulting in abnormalities such as poor water quality and poor water discharge.
- Please scan the QR code to watch the cleaning steps of the CNC silent pump.



Scan to watch the cleaning video



Scan to watch the installation video

FAQ

*For more customer support: info@petkit.com

I. About Indicator Light Faults:

- The indicator light does not light up after power-on: Please re-plug and replace the adapter or USB power cord with a new one. If it still does not light up, please contact info@petkit.com to replace the original USB cable.
- Failure to reset after filter replacement (the filter indicator light is not off): Please first confirm that the SMART/NORMAL mode can be switched normally when double clicking. Or long press for reset after power off and restart. If it still can't be reset, please contact info@petkit.com.
- Orange and blue lights flashing alternately (*Orange SOLO: alternate flashing of grass-green and orange light) indicates unstable output voltage, please replace the adapter with a new one or contact info@petkit.com.

12

FAQ

II. About Filter

- A little black powder floating in the water: A little of non-toxic and harmless coconut shell activated carbon used for the filter element will float out with the water flow, which is a normal phenomena. Please feel free to use.
- A "click" sound of the pump in use: Due to the circulation of water flow, the coconut shell activated carbon floating in the water may be absorbed by the pump. Please check and clean up in time.

III. About water outflow faults

- No water outflow after switching to normal mode:
 - Please check whether the light is flashing. If the orange light is still flashing when barrel is full of water, please contact info@petkit.com.
 - Remove the tray set and check the pump for operating or clogging. If the pump is working properly, try to replace the filter element with a new one. If it is not resolved, please contact info@petkit.com or clean the tray set and then align it with the water outlet.
 - If the pump does not work, clean the pump according to the pump cleaning video instructions (see the QR code of the manual for details, be sure to carry out in the power off state). If the problem cannot be solved after the above steps, please contact info@petkit.com.
- The water outflow becomes small:
 - Please check the filter first, and then water pipe or pump for blocking. Disassemble and clean them and then try again, or contact info@petkit.com.
 - This may be caused by too low water level due to the small quantity of water in the water storage barrel. Please refill with water as appropriate.
 - Check whether the filter element tray water outlet is aligned with the bottom water pump outlet.

13

FAQ

- Start to overflow after use for a period of time: If the filter is used too long, the dirty residue on the surface will affect the seepage effect of the filter. Please replace the filter element in time. Or check whether there is dirt clogging in water pipes and pump, and try again after cleaning.

IV. The Fountain is immersed in water and cannot work normally

It is recommended that you unplug the power supply, remove the bottom screws, open the bottom cover to clean the water inside, place the bottom cover up in a ventilated place for 12 hours to dry, and then confirm whether the function is OK. If it still does not work, contact info@petkit.com.

BASIC PARAMETER INFORMATION

Product Name	PETKIT EVERSWET SOLO Smart Pet Drinking Fountain
Product model	P4103
Overall size	160mm X 160mm X 158mm
Recommended pet type	Cats and small-sized dogs
Complete machine weight	About 0.65kg
Rated voltage	5VDC
Rated power	2W

14

01V1.0

The device has been approved for use in EU countries and is therefore provided with the **CE mark**. All necessary documentation is available on the website: www.electric-collars.com
Changes to technical parameters, properties and printing errors reserved.

Service center and distribution

Reedog, sro

Sedmidomky 459/8 101

00 Prague 10

Phone: +1 646 980 4569

Email: info@electric-collars.eu