



Reedog anti-bark hand training device UL70

Operation guide



Thank you for choosing Reedog!

Warning:

Different dogs may react differently to ultrasound.

- Normal human hearing ranges from 20Hz - 20kHz, dogs hear from 15Hz - 120kHz.

The ultrasound device emits sound at a frequency of 25kHz, which is the most sensitive frequency.

- The maximum distance is 5 meters.
- Do not use on aggressive dogs.
- This device is not intended for children as a toy!
- Avoid contact with water, the device is not waterproof.
- Do not use on dogs under 6 months of age.
- Training is more effective in shorter 10 to 15 minute intervals.
- Improper use can cause harm to health.

How to use the device

1. Hold the device in your hand.
2. When you press the button, you will hear a short sound and see a green light signal.
3. Press the button once, the device will emit one signal.
4. Press the button and hold in your hand, the device emits a continuous sound, which will automatically end after 8 seconds.
5. Press the button only if you are within five meters of the dog.
6. If the device is discharged, the red light signal will light up. In this case, recharge the device.
7. The ultrasonic signal can be heard by other dogs within this range.

Sound button:

- Press the button once, the device emits one sound. Press and hold the button, the device will emit a continuous sound for 8 seconds.

Flashlight Button:

Press it and the device will light up as a flashlight. If you press it again, the device will start flashing. Press again to turn off the flashlight.

Mode button:

Move it up: the device emits ultrasound - Move it to the middle: the device alternates high and low ultrasound - Move it down: the device goes to normal mode.

Charging:

- Connect the device with a 5V DC cable. If the device is charging, the red light is on. When the device is fully charged, the green light will turn on.

The device has been approved for use in EU countries and is therefore provided with the **CE mark**. All necessary documentation is available on the website: www.electric-collars.com
Changes to technical parameters, properties, and printing errors are reserved.

Service center and distribution

Reedog s.r.o.

Sedmidomky 459/8

Praha 10 - Michle, 101 00

Phone: +1 646 980 4569

Email: info@reedog.eu

