

# 正面

### Pet Fountain

#### Before we start: Care instructions

To keep providing fresh, clean water for your pet, remember these three simple tasks:

**Refill often.** Keep the water level up. The pump is designed to work in at least one inch of water. The pump can fail if it runs dry.

**Clean your pump and your fountain.** Take your pump and fountain apart to clean with soap and water every two to four weeks. Be careful not to get soap in the filters, as it will not rinse out.

**Replace your filters.** Replace the carbon filter every four weeks when you clean your fountain. Replace the foam filter every two months.

#### What you have:

#### Setup instructions

##### 1 Schematic diagram for pump installation

Put the pump according to the direction

Put the cord in the notch

# 背面

### 2 Install the filter:

Take out the filter unit, soak it in clean water. Rinse it slightly with water

install the filter in the filter tray

### 3 Install the lid & flower

Install the lid

Install the flower in sequence, connect the power adaptor

### Use instructions

Place the fountain where your pet will use it. Fill the vessel with water, leaving a half inch of space between the water and the rim. Make sure your hands, the cord and the power adaptor are dry.

**Keep health and happiness flowing!**

### To extend product life, please clean the pump every 2 weeks.

1. Remove the Pump Cover
2. Clean the pre-filter grate with soap and warm water.
3. Remove the Impeller and clean the parts with soap and warm water.

**Cautions**

1. Be sure to shut down and disconnect the power supply for safety when the equipment is not in use.
2. This product is for indoor use only.
3. The power adapter and wire plug must not be flooded during cleaning.
4. This product is not allowed to run without water.
5. Please disconnect the power supply before maintaining and cleaning the machine.

The device has been approved for use in EU countries and is therefore provided with the **CE mark**. All necessary documentation is available on the website: [www.electric-collars.com](http://www.electric-collars.com)  
Changes to technical parameters, properties and printing errors reserved.

### **Service center and distribution**

Reedog, sro

Sedmidomky 459/8 101

00 Prague 10

Phone: +1 646 980 4569

Email: [info@electric-collars.eu](mailto:info@electric-collars.eu)