

English

PETKIT


EVERSWEET WIRELESS SUS304

User Manual



Please read the User Manual carefully before using the product and keep it properly.

| PRODUCT DESCRIPTION



*Note: In order to provide a better user experience, we will be implementing periodic product enhancements. Product images shown for illustration purpose only. Actual product may vary from the image shown on the box. For any discrepancies, please refer to the actual product.

2

| App DOWNLOAD



Scan to download PETKIT App
Download the App from the App store or Android App Market: PETKIT. Enter the main page of the App and click "+" to add the device. Follow the instructions in the App to pair your device.
*Using the app, you can adjust the water flowing mode.

| SET UP AND USE




Scan to watch an instructional video on how to set up and use the product

| MAINTENANCE AND CLEANING



Scan to watch an instructional video on how to maintain and clean the product

| INDICATOR LIGHT



- SMART MODE
Green light on: Interrupted welling up of water.
(Specific parameters can be set up in the App by yourself. The default setting is water flowing for 3 minutes and stopping for 3 minutes.)
- NORMAL MODE
Blue light on: Uninterrupted welling up of water.
- FILTER INDICATOR LIGHT
Flashing green light: The filter needs to be replaced.
(After replacing the filter element, please complete the reset in the App.)
- WATER SHORTAGE INDICATOR
Flashing blue light: Indicates water shortage and the device is in standby. The device can resume normal operation after refilling.
- DEVICE POWER FAILURE
Alternate flashing of blue and green light: Indicates power failure. Please plug the USB power cord to restart the device, or contact customer service.

| A MESSAGE TO OUR VALUED CUSTOMERS

- Thank you for choosing to purchase the PETKIT EVERSWEET WIRELESS(SUS304). We at PETKIT have done our best to make life easier for you and your pet through the miracle of technology.
- Before using this product, please carefully read the user's manual. By setting up and using this product, you acknowledge that you have already read and accept the safety measures listed below.
- We are not liable and will not accept responsibility for any accidents or injuries that result from improper use of this product.
- Concerning this notice, we reserve the right of interpretation and revision.

3

| USER SAFETY GUIDE

- * Failure to follow the safety guide outlined below may result in device malfunction or other unexpected accidents.
- Please install and use product exactly as instructed in the User's Manual.
- Pets under the age of 3 months should not use this product.
- For indoor use only.
- Even though this product uses low current, pets can still damage the power cord if they chew on it, preventing the product from getting power. Please ensure pets use product as intended.
- Please make sure the device is placed on a level surface. Do not overturn the device, otherwise it may not function properly or spill water.
- Do not immerse or soak the main body base in water.
- Please clean the stainless steel part of the product before use.
- If the device is not used for a long period of time or is moved, please unplug the power cord.
- Children should only be allowed to operate this device under the supervision of an adult.
- Repairs should be done under the guidance of a professional to avoid safety hazards.
- Please check the remaining water in the drinking fountain before taking your vacation.
- If you encounter any problems while using this product, please contact us immediately.

| BASIC SPECIFICATIONS

Product Name	PETKIT EVERSWEET WIRELESS (SUS304)	Product Weight	1.28kg
Product Code	P4108	Wireless Connectivity	Bluetooth
Product Dimensions	195*195*148mm	Rated Voltage	5V
Intended Uses	For cats and small breed dogs	Rated Power	2W
Product Materials	ABS, Silicon, SUS304, PP	Product Capacity (volume)	1.8L

4

Disposal

The European directive 2012 / 19 / CE on Waste Electrical and Electronic Equipment(WEEE), requires that old household electrical appliances must not be disposed in the normal unsorted municipal waste stream. Old appliances must be collected separately in order to optimize the recovery and recycling of the materials they contain and reduce the impact on human health and the environment. The crossed out "wheeled bin" symbol on the product reminds you of your obligation that when you dispose of the appliance it must be separately collected. Consumers should contact their local authority or retailer for information concerning the correct disposal of their old appliance.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and ; (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

IC warning

- English:
This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:
(1) This device may not cause interference, and
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

- French:
Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:
(1) l'appareil ne doit pas produire de brouillage, et
(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

5

The device has been approved for use in EU countries and is therefore provided with the **CE mark**. All necessary documentation is available on the website: www.electric-collars.com
Changes to technical parameters, properties and printing errors reserved.

Service center and distribution

Reedog, sro

Sedmidomky 459/8 101

00 Prague 10

Phone: +1 646 980 4569

Email: info@electric-collars.eu