



AI Cat Litter Box (Pro - X)

SCOOPER User Manual



Toll free: +1 833 440 2772 Email: support@catlink.cn

Thank you for purchasing a CATLINK AI Cat Litter Box Scooper Pro - X!

CATLINK aims to develop products that keep your pets happy and make your life easier. This manual will help you get the most out of your Scooper Pro - X. We will guide you through the setup process, as well as provide you with useful tips and advices.

There are many features to explore with the Scooper Pro - X, so keep this manual handy for future reference. If you need assistance, or a little extra time, please email us at support@catlink.cn or call us +1 833 440 2772. Enjoy your Scooper Pro - X, and Enjoy your Freedom!

CATLINK


Important Safety Instructions

- **Always** be sure any cat in your household that might use the Scooper Pro – X weighs at least 3.3 pounds. Cats must weigh 3.3 to 22 pounds to safely use the Scooper Pro – X.
- **Always** place the Scooper on a firm, level surface. Avoid soft, uneven, or unstable flooring, which may affect the ability of the unit to detect your cat.
- **Always** unplug the unit before servicing.
- **Never** force your cat into the Scooper.
- **Never** put anything in the unit other than clumping litter or litter beads that are small enough to pass through the screen.
- **Never** sit on or place anything on top of the Scooper.
- **Never** push the Scooper against a wall or into a corner (must not be touching any walls).
- **Never** remove the Globe or Bonnet while the unit is rotating or turn the unit on if the Globe or Bonnet are removed.
- **Never** wet or submerge the Bonnet or Base.
- **Never** allow children and persons with reduced physical, sensory, or mental capabilities or lack of experience and knowledge use, clean, or maintain the Scooper without supervision, instruction concerning its use in a safe way, and understanding of the hazards involved. Children below 8 years of age should not be allowed contact with the Scooper.
- **Never** allow children or others to play with the Scooper.
- **Never** use an external power supply other than the one provided with the unit.
If the external power supply is damaged, please contact us for a replacement.


【Table of Contents】

【Product Structure】	01
【Packing List】	02
【Setting Up Your Scooper Pro - X】	03
1.Placement	03
2.Power and Initial Test Cycle	04
3.WIFI Connection	05
4.Cat Litter	07
【Control Panel – Button Functions】	08
1.Control Panel	08
2.Button Functions	09
【Indicator Lights】	10
【Working Mode】	11
【Protection Mechanism】	12
【Replace All Cat Litter】	13
【Cleaning and Attentions】	14
【Troubleshooting】	16
【Accessories】	18
【Product Specifications】	19
【Compare CATLINK Models】	20
【Customer Service】	21


【Product Structure】



【Packing List】



AI Cat Litter Box




Power Adapter



Trash Liner




User Manual
(Warranty Card)




Suitable for
Bentonite Cat Litter

Two Screens
(2 options, choose one to use)



Suitable for
Mixed Cat Litter




Carbon Filter Box

The carbon filter box has been placed in the waste box. CATLINK recommends taking this part out every month and exposing it to the sun, and replacing it every 2 months.

【Setting Up Your Scooper Pro - X】


Once you have assembled the product and confirmed that the package is complete, get started by following the steps below.

1.Placement



1

Make sure that the unit is placed on flat and solid ground with no other object at the bottom. Avoid soft, uneven, or unstable flooring.



2

Locate the unit near a power outlet. Ensure the unit isn't pushed against a wall or into a corner (must not be touching any walls), and there is no other objects are placed on the top.




3


Make sure that the unit is close to the Wi-Fi signal and far away from electrical appliances with strong interference.

2. Power and Initial Test Cycle


- 1 Check whether the Trash Liner is properly placed, and properly push the Waste Drawer back to its position.



- 2 Plug the small end of the power supply into the power input at the back of the Base. Then plug the adapter into a wall outlet.



- 3 The unit will perform a test cycle every time it is plugged in. DO NOT touch the unit or buttons during this process. It takes about 3 minutes.



3.WIFI Connection

NOTE:

- 1) Please place the litter box as close to the router as possible, and make sure the litter box is powered on.
- 2) Please authorize the location information, and the Android phone also needs to turn on GPS.
- 3) Please note that the WIFI name can only contain letters and numbers, so as not to affect the connection.
- 4) Please use 2.4GHz WIFI, 5GHz WIFI is not supported, as well as hotels, airports, etc. that require special certification of WIFI.

1 Download the CATLINK APP in the application market of your phone or scan the QR code.



CATLINK APP



For ANDROID




For IOS

- 2** Register your account in the app and log in. (Please authorize location, please turn on GPS for Android.)
- 3** On the DEVICE page, click the '+' in the upper right corner, select the SCOOPER, and follow the instructions to complete the WIFI connection. (Before connecting, your mobile phone needs to be connected to WIFI)


Step1.

Long press the 2 buttons until you hear 2 beeps. Make sure that the WIFI indicator is flashing, click NEXT on the APP.



Step 2.

Enter your WIFI password. Click NEXT.




Step 3.

Waiting for a few moments. During this process, please ensure that the phone and the device are kept close to each other.

Da da! Device added successfully, the WIFI indicator is solid blue.

If you can't find your device, please pull down the DEVICE page to refresh.



Connection Failed


Please turn off the power, give it a try one more time. Please read the NOTE under the title [WIFI Connection] of this chapter, to ensure that there are no errors in the process.

If the connection is unsuccessful, please feel free to contact us.

(Toll free:+1 833 440 2772, Email:support@catlink.cn)

4. Cat Litter

Fill the Globe through the opening with clumping litter until it meets the Fill Line when spread flat. Be careful not to overfill the Globe.



The Scooper Pro - X litter sifting system requires clumping litter or mixed litter to work properly. We recommend a high-quality, clay-clumping litter.


DO NOT use litters that are strictly absorbent, non-clumping, loose-clumping, news- paper-based, or wood-based pellets.

If you are using a litter alternative not listed here, please contact Customer Service to make sure you are using a compatible litter.

Congratulations!
Your Scooper Pro - X is now ready to use.

【Control Panel - Button Functions】

1.Control Panel



Error Indicator



WIFI Indicator



Panel lock Indicator



Auto Mode Indicator



Timer Mode Indicator



Clean/ Pause Button



Manual Mode Indicator









Empty Mode Indicator











Mode Button





2.Button Functions

Button		Operation	Explanation
Clean/ Pause		One Click Start Clean/ Pause	
Mode Switch		One Click Switch Cleaning Mode	Timer mode only works after WIFI is successfully connected
Panel Lock	 + 	Press and hold the Mode Switch and the Clean/Pause button for 3 seconds, release the buttons when you hear a beep.	When the Panel Lock indicator light is on, it means the panel is locked successfully. If you want to unlock, repeat the above operations. [Note] This function can also be turned on or off on CATLINK APP.
WIFI Connection	 + 	Press and hold the Mode Switch and Clean/Pause buttons, release them after hearing 2 beeps, enter the WIFI pairing mode, and complete the pairing with the CATLINK APP	When the WIFI indicator is always on, it means that the WIFI pairing has been completed.

【Indicator Lights】

Indicator Lights		Status	Explanation
Auto Mode		ON	The unit is in Automatic Mode and the cat can use it normally.
Manual Mode		ON	The unit is in Manual Mode and the cat can use it normally. Manual operation is required for the unit to start cleaning.
Timer Mode		ON	The unit is in Timer Mode and the cat can use it normally. At the set time, the unit automatically cleans.
Empty Mode		ON	The unit is in Empty Mode. Cats are forbidden to use while working.
Error Indicator		ON	Under weighing protection, the unit suspends operation.
		Flashing Quickly	Under radar protection, the unit suspends operation.
		Flashing Slowly	Waste Drawer is full.
Error + Panel Lock		Flashing Fast	Under Anti-pinch protection, the unit suspends operation.
		Flashing Slow	Under Motor stalled protection, the unit suspends operation.
WIFI		OFF	WIFI not connected
		ON	WIFI connected
		Flashing	WIFI pairing
Panel Lock		OFF	Panel Lock off
		ON	Panel Lock On

【Working Mode】


Mode	Panel Indicator	Explanation
Auto		When the cat leaves the Globe, the timer starts. After 5 minutes by default, the litter box will automatically clean. [Note] The Wait Time can be modified in the APP.
Manual		Manual control to start and pause cleaning.
Timer		Only after the WIFI pairing is successful, you can set the time for regular cleaning on the APP.
Empty		Empty the cat litter in the Globe.

【Protection Mechanism】


Protection Function	Priority	Explanation
Radar	Level 1	During the rotation of the Globe, if a moving object enters, radar protection will be triggered first, and the Globe will stop rotating. When the object is detected to leave, the Globe will resume rotation.
Weighing	Level 2	During the rotation of the Globe, if a object over 3.3lbs enters, the weighing protection will be triggered, and the Globe will stop rotating. When the object is detected to leave, the Globe will resume rotation.
Anti-pinch	Level 3	When the Globe's litter outlet is facing downwards and the anti-pinch device is triggered during rotation, the globe will release the maximum litter outlet space and stop rotating. This protection can only be lifted after human intervention.
Motor Stalled	Level 4	The Globe will stop rotating when the motor resistance suddenly increases during the rotation. This protection can only be cancelled with human intervention.

【Replace All Cat Litter】


- 1** Click the Mode button to switch to Empty mode.




- 2** Click the Clean/Pause button and the Globe will rotate clockwise.






- 3** After all the cat litter has fallen into the Waste Drawer, click the Clean/Pause button again, and the Globe will return to its original position.



- 5** Add new cat litter, below the MAX mark, then click the Clean / Pause button to clean once to smooth the cat litter.




- 4** Take out the Waste Drawer, seal and discard the waste cat litter; put on a new Trash Liner, and push the Waste Drawer back to its original position.




【Cleaning and Attentions】


- 1** Power off after emptying the cat litter,
Refer to the steps for **【Replace All Cat Litter】**




- 2** Remove the top cover, If it is a luxury model,
please remove the connecting wire as shown
in the figure before removing the top cover.





- 3** Take out the Globe
(Pay attention to removing the support rod
of the rotating shaft on the back of the Globe).





- 4** Take out the Waste Drawer and the Carbon Filter
(The Carbon Filter is recommended to expose
it to the sunshine once a month and replace it
every two months).






- 5** Globe and Waste Drawer can be washed directly (be sure to wipe and dry thoroughly after washing).









- 6** Top Cover and Base can be wiped with wet wipes (Due to the electronic parts inside, it cannot be washed directly).






- 7** After cleaning up, install a new Carbon Filter back to the Waste Drawer, and follow the reverse steps to assemble the device properly.








【Troubleshooting】

Trouble	Solution	Steps
Stop operation caused by Radar protection, weighing protection, full Waste Drawer.	Cancel manually	Click the Clean/ Pause button once. 
Stop operation caused by Anti-pinch was triggered.	Cancel manually	Click the Clean/ Pause button once. 
The amount of cat litter is not accurate.	Reset cat litter to ZERO	1 Empty all cat litter. 
		2 Empty all cat litter. 
		3 Long press the Mode Switch button, release it after hearing 2 beeps, the Manual Mode indicator and the Mode Switch button indicator flash. 
		4 Immediately press and hold the Mode Switch button again, release it after hearing 2 beeps. 
		5 Operation complete.

Trouble	Solution	Steps
Weighing data is inaccurate.	Weighing calibration	1 Prepare reference object. Can use 3.3lbs items, 3 bottles of 16.9 fl oz water.
		2 Power off and restart. 
		3 After the Globe starts to rotate, put the 3.3lbs item into the Globe. 
		4 Long press the Mode Switch button, release it after hearing two beeps, the Mode Switch indicator flashes. 
		5 After the indicator light of the Mode Switch button is always on and a beep sounds, the weighing calibration is completed.

【Accessories】

Name	Product pictures
Trash Liner	
Carbon Filter Box	
Ramp	
Clumping Litter	
Odor Remover	

You can order the above products on Amazon.com or www.catlinkus.com




Amazon.com



www.catlinkus.com

【Product Specifications】

Product Name	CATLINK AI Cat Litter Box (Pro - X) - SCOOPER
Product Model	CL-07 / CL-08
Main Material	PP
Product Size	23.62 x 22.83 x 27.95 inch
Rated Voltage	12V 
Rated Power	5W
Applicable Scope	Cat (3.3-22 lbs)
Weight	24.25 lbs
Carried Standard	GB 4706.1-2005

【Compare CATLINK Models】

Functions	Pro-X Standard	Pro-X Luxury
Night Light	X	√
Temperature and Humidity Sensor	X	√
Litter Level	X	√
Weight Sensor	√	√
Anti-pinch Sensor	√	√
Radar Sensor	√	√
UV Sterilization	√	√
Deodorization	√	√

NOTE:

Deodorization function: This function is enabled by default.
Closing and mode adjustment are not supported.

【Customer Service】

We will provide customers with a one-year free warranty service.
If you have questions or need assistance, contact us!

Phone Support

+1 833 440 2772

Mon–Fri: 10AM–6PM EST

Email Support

support@catlink.cn 24/7



Toll free: +1 833 440 2772 Email: support@catlink.cn

The device has been approved for use in EU countries and is therefore provided with the **CE mark**. All necessary documentation is available on the website: www.electric-collars.com
Changes to technical parameters, properties and printing errors reserved.

Service center and distribution

Reedog, sro

Sedmidomky 459/8 101

00 Prague 10

Phone: +1 646 980 4569

Email: info@electric-collars.eu